

Reference Guide

Bison DR + GNSS Receiver

For use with:

Bison DR + GNSS receiver, P/N 99988-XX

Version 1.0
Revision A
July 2015



Legal Notices

Corporate Office

Trimble Navigation Limited
Embedded / IVN Division
935 Stewart Drive
Sunnyvale, CA 94085
U.S.A.
Phone: 1-800-767-4822
+1-408-481-8258
www.trimble.com

Support Offices

Trimble Navigation Limited
Embedded / IVN Division
935 Stewart Drive
Sunnyvale, CA 94085
U.S.A.
Phone: 1-800-767-4822

Copyright and Trademarks

© 1997–2015, Trimble Navigation Limited.

Trimble, the Globe & Triangle logo, Condor, and OmniSTAR are trademarks of Trimble Navigation Limited, registered in the United States and in other countries.

All other trademarks are the property of their respective owners.

All rights reserved. No part of this manual may be copied, reproduced, translated, or reduced to any electronic medium or machine-readable form for any use other than with the Bison DR + GNSS device.

Release Notice

This is the July 2015 release (Revision A) of the *Bison DR + GNSS Receiver Reference Guide*, part number 99988-XX-UG.

This reference guide is intended for use by system integrators, service providers, and application developers (“resellers”). It is not intended for end-users of the device. It is the responsibility of resellers to develop and provide end-user documentation.

LIMITED WARRANTY TERMS AND CONDITIONS

Product Limited Warranty

Subject to the following terms and conditions, Trimble Navigation Limited (“Trimble”) warrants that for a period of one (1) year from date of purchase this Trimble product (the “Product”) will substantially conform to Trimble’s publicly available specifications for the Product and that the hardware and any storage media components of the Product will be substantially free from defects in materials and workmanship.

THIS PRODUCT LIMITED WARRANTY IS PROVIDED TO RESELLERS AND TO RESELLERS ONLY. THE RESELLER IS SOLELY RESPONSIBLE FOR ANY AND ALL WARRANTIES MADE TO ITS CUSTOMERS, AND TRIMBLE MAKES NO WARRANTIES, EXPRESS OR IMPLIED, AND SHALL HAVE NO OBLIGATIONS OR LIABILITY TO RESELLER’S CUSTOMERS OR END-USERS OF THE PRODUCT. RESELLER SHALL NOT MAKE ANY REPRESENTATIONS OR WARRANTIES ON TRIMBLE’S BEHALF, AND SHALL FULLY INDEMNIFY, DEFEND AND HOLD TRIMBLE HARMLESS FROM ANY BREACH OF THE FOREGOING.

IF RESELLER DISTRIBUTES PRODUCT TO END-USER CUSTOMERS, RESELLER SHALL BE SOLELY RESPONSIBLE FOR PREPARING AND PROVIDING PRODUCT WARRANTIES AND PRODUCT LITERATURE TO END-USERS.

Warranty Remedies

If the Trimble Product fails during the warranty period for reasons covered by this limited warranty and you notify Trimble of such failure during the warranty period, Trimble will repair OR replace the nonconforming Product with new, equivalent to new, or reconditioned parts or Product, OR refund the Product purchase price paid by you, at Trimble’s option, upon your return of the Product in accordance with Trimble’s product return procedures then in effect.

How to Obtain Warranty Service

To obtain warranty service for the Product, please contact your local Trimble authorized dealer. Alternatively, you may contact Trimble to request warranty service at +1-408-481-6940 (24 hours a day) or e-mail your request to trimble_support@trimble.com. Please be prepared to provide:

- your name, address, and telephone numbers

- proof of purchase
- a copy of this Trimble warranty
- a description of the nonconforming Product including the model number
- an explanation of the problem

The customer service representative may need additional information from you depending on the nature of the problem.

Warranty Exclusions and Disclaimer

This Product limited warranty shall only apply in the event and to the extent that (a) the Product is properly and correctly installed, configured, interfaced, maintained, stored, and operated in accordance with Trimble’s applicable operator’s manual and specifications, and; (b) the Product is not modified or misused. This Product limited warranty shall not apply to, and Trimble shall not be responsible for, defects or performance problems resulting from (i) the combination or utilization of the Product with hardware or software products, information, data, systems, interfaces, or devices not made, supplied, or specified by Trimble; (ii) the operation of the Product under any specification other than, or in addition to, Trimble’s standard specifications for its products; (iii) the unauthorized installation, modification, or use of the Product; (iv) damage caused by: accident, lightning or other electrical discharge, fresh or salt water immersion or spray (outside of Product specifications); or exposure to environmental conditions for which the Product is not intended; (v) normal wear and tear on consumable parts (e.g., batteries); or (vi) cosmetic damage. Trimble does not warrant or guarantee the results obtained through the use of the Product, or that software components will operate error free.

NOTICE REGARDING PRODUCTS EQUIPPED WITH TECHNOLOGY CAPABLE OF TRACKING SATELLITE SIGNALS FROM SATELLITE BASED AUGMENTATION SYSTEMS (SBAS) (WAAS/EGNOS, AND MSAS), OMNISTAR, GNSS, MODERNIZED GNSS OR GLONASS SATELLITES, OR FROM IALA BEACON SOURCES: TRIMBLE IS NOT RESPONSIBLE FOR THE OPERATION OR FAILURE OF OPERATION OF ANY SATELLITE BASED POSITIONING SYSTEM OR THE AVAILABILITY OF ANY SATELLITE BASED POSITIONING SIGNALS.

THE FOREGOING LIMITED WARRANTY TERMS STATE TRIMBLE’S ENTIRE LIABILITY, AND YOUR EXCLUSIVE REMEDIES, RELATING TO THE TRIMBLE PRODUCT. EXCEPT AS OTHERWISE EXPRESSLY PROVIDED HEREIN, THE PRODUCT, AND ACCOMPANYING DOCUMENTATION AND MATERIALS ARE PROVIDED “AS-IS” AND WITHOUT EXPRESS OR IMPLIED WARRANTY OF ANY KIND, BY EITHER TRIMBLE OR ANYONE WHO HAS BEEN INVOLVED IN ITS CREATION, PRODUCTION, INSTALLATION, OR DISTRIBUTION, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, TITLE, AND NONINFRINGEMENT. THE STATED EXPRESS WARRANTIES ARE IN LIEU OF ALL OBLIGATIONS OR LIABILITIES ON THE PART OF TRIMBLE ARISING OUT OF, OR IN CONNECTION WITH, ANY PRODUCT. BECAUSE SOME STATES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON DURATION OR THE EXCLUSION OF AN IMPLIED WARRANTY, THE ABOVE LIMITATION MAY NOT APPLY OR FULLY APPLY TO YOU.

Embedded Software/Firmware

The Product and associated tools, if any, may contain embedded software/firmware, which is licensed, not sold, and is only for use within the Product as an integral part thereof. Such embedded software/firmware (which includes all updates thereto) contains valuable trade secrets and is proprietary to Trimble and its suppliers. To the greatest extent permitted by law, such embedded software/firmware may not be modified, copied, disassembled, decompiled or reverse engineered. Trimble reserves all other rights.

Limitation of Liability

TRIMBLE’S ENTIRE LIABILITY UNDER ANY PROVISION HEREIN SHALL BE LIMITED TO THE AMOUNT PAID BY YOU FOR THE PRODUCT. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL TRIMBLE OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGE WHATSOEVER UNDER ANY CIRCUMSTANCE OR LEGAL THEORY RELATING IN ANYWAY TO THE PRODUCTS, SOFTWARE AND ACCOMPANYING DOCUMENTATION AND MATERIALS, (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF DATA, OR ANY OTHER PECUNIARY LOSS), REGARDLESS OF WHETHER TRIMBLE HAS BEEN ADVISED OF THE POSSIBILITY OF ANY SUCH LOSS AND REGARDLESS OF THE COURSE OF DEALING WHICH DEVELOPS OR HAS DEVELOPED BETWEEN YOU AND TRIMBLE. BECAUSE SOME STATES AND JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY OR FULLY APPLY TO YOU.

PLEASE NOTE: THE ABOVE TRIMBLE LIMITED WARRANTY PROVISIONS WILL NOT APPLY TO PRODUCTS PURCHASED IN THOSE JURISDICTIONS (E.G., MEMBER STATES OF THE EUROPEAN ECONOMIC AREA) IN WHICH PRODUCT WARRANTIES ARE THE RESPONSIBILITY OF THE LOCAL TRIMBLE AUTHORIZED DEALER FROM WHOM THE PRODUCTS ARE ACQUIRED. IN SUCH A CASE, PLEASE CONTACT YOUR LOCAL TRIMBLE AUTHORIZED DEALER FOR APPLICABLE WARRANTY INFORMATION.

Official Language

The official language of these terms and conditions is English. In the event of a conflict between English and other language versions, the English language shall control.

NOTICE:

Changes or modifications made to this equipment not expressly approved Trimble Navigation Limited may void the FCC authorization to operate this equipment.

This device complies with Part 15 of the FCC Rules

Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the device.
- Connect the equipment into an outlet on a circuit different from that to which the device is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTICE:

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Notice to Our European Union Customers

For product recycling instructions and more information, please go to www.trimble.com/ev.shtml.

Recycling in Europe: To recycle Trimble WEEE (Waste Electrical and Electronic Equipment, products that run on electrical power.), Call +31 497 53 24 30, and ask for the "WEEE Associate". Or, mail a request for recycling instructions to:

Trimble Europe BV
c/o Menlo Worldwide Logistics
Meerheide 45
5521 DZ Eersel, NL



Contents

	Legal Notices	2
1	Introduction	8
	Key features	9
	System block diagram	10
	General recommendations	11
	Carrier board	11
2	Performance Specifications	12
	Global Navigation Satellite System (GNSS)	13
	Dynamic limits	13
	Fix rate	13
	GNSS accuracy	14
	Sensitivity	14
	Dead reckoning (DR)	15
	Time to first fix - DR	15
	Fix rate	15
	Electrical	15
	Normal operating conditions	15
	Recommended Power Sequence	15
	RF	16
	Data I/O	16
	PPS	17
	Recommended GNSS antenna characteristics	17
	Environmental	18
3	Interface Characteristics	19
	Pin-out assignments	20
	Detailed pin description	21
	RFIN	21
	OPEN/SHORT	21
	XRESET	22
	VCC	22
	RXD	22
	TXD	22
	Speed signal input sensor	22
	FWD/REV direction switch	22
	RESERVED	22
4	Orientation and Calibration	23
	General Bison module coordinate system	24
	General vehicle coordinate system	24

	BN1919 Gyro coordinate system	25
	Bison Accel coordinate system	25
	Gyro mounting angle	26
	Accelerometer mounting angle	28
	Calculating the gyro orientation vector	29
	Dead-reckoning (DR) calibration	31
	Purpose of dead-reckoning calibration	31
	General calibration requirements	31
5	Software	32
	Port configuration	33
	Tools	33
	Software	33
	Features	33
	Performance requirements	37
	Timing or latency requirements	38
	Upgrade requirements	38
	Interfaces	38
	Communication protocols	39
6	Mechanical Specifications	40
	Form factor	41
	Mechanical drawing	42
	Layout	43
	Suggested customer solder mask	43
	Suggested customer pad pattern	43
	Suggested customer paste pattern	44
7	Storage and Handling.	45
	Moisture	46
	Moisture Sensitivity Level	46
	Moisture precondition	46
	Baking procedure.	46
	Soldering paste	47
	Solder reflow	47
	Recommended solder profile	47
	Optical inspection	48
	Cleaning	48
	Repeated wave soldering	48
	Wave soldering	48
	Hand soldering	48
	Rework	49
	Conformal coating	49
	Metal shield grounding	49
	PCB fabrication	49
A	HIPPO Protocol	50
	Soft event and fatal error logging and reporting	51
	Available HIPPO messages.	52

HIPPO protocol rules	53
General message structure rules	54
Report message structure (Module to Host)	55
Command message structure (Host to Module)	56
Chained messages	56
Post-formatting: HCC stuffing before transmission	57
Pre-parsing: HCC unstuffing after reception	57
Command messages	57
Set class	58
Query class	59
System class	60
Report class	60
Report message code assignment	61
Data report packets	61
Diagnostic report packets	61
Event log queue	70
Theory of Operation	70
Fatal errors	70
Soft events	72
B NMEA 0183 Protocol	78
Introduction	79
Standard NMEA messages	79
Proprietary NMEA messages	79
NMEA protocol overview	80
NMEA 0183 communication interface	80
NMEA 0183 message structure	80
Field definitions	81
Message options	82
Standard NMEA messages	82
GGA: Global Positioning System Fix Data	83
GSA: DOP and Active Satellites	83
GSV: GNSS Satellites in View	84
RMC: Recommended Minimum Specific GNSS/Transit Data	84
VTG: Course over Ground and Ground Speed	85
ZDA: Time and Date	85
Proprietary NMEA messages	86
AN: Antenna Configuration	86
BA: Antenna Status	86
EM: Enter Monitor Mode	87
NM: Automatic Output Interval and Mask	87
PT: Port Configuration	88
RT: Reset Device	89
TP: Temperature Measurement	89
VR: Version Information	90
C Reference Circuit	92
Bison reference circuit diagram	93
Circuits using externally powered antennas	94

Bison reference circuit for antenna Open/Short detection using an externally
powered 3.5 V antenna 95

Introduction

In this chapter:

- [Key features](#)
- [System block diagram](#)
- [General recommendations](#)
- [Carrier board](#)

This document describes the hardware and software characteristics of the Trimble® Bison module, a 19 x 19 mm SMT-sized dead-reckoning (DR) host-independent positioning GNSS receiver.

Key features

The Bison BN1919 module is a world class DR + GNSS module that contains a microprocessor and an integrated GNSS receiver capable of using GPS and GLONASS constellations, combined with a three-axis gyro and three-axis accelerometer to provide a positioning solution even in the harshest of automotive environments. Together, these elements allow the Bison module to easily determine the complete vehicle dynamics. The Bison GNSS engine can acquire, track, and use GPS and GLONASS satellites anywhere in the world.

The term **dead reckoning** (DR) goes back to sixteenth century sailing ships and navigation and refers to the ability to calculate your position using a starting position and calculating distance and direction traveled using time, speed, and heading. Although this method provides accurate changes in position (given accurate inputs), the overall calculation of position will eventually show drift as measurement and propagation errors build up. Dead reckoning alone cannot "fix" a position. The mariners of old used astronomical observations to help provide fixes; today we can use GNSS positions.

The Bison DR output is our best estimate of position combining all navigation information available, including GNSS. If the user supplies the necessary data (GNSS RF input, speed pulses, direction) we don't recommend that the customers switch between using GNSS position and DR position. The DR-position calculation has algorithms that will sometimes reject GNSS positions if the measurement quality could degrade the position calculation. This is the value of using DR—it is intended to extend the position availability to areas where GNSS is unreliable.

The Bison module has an onboard low-noise amplifier (LNA) that is compatible with both active and passive antenna implementations. It includes an onboard RTC and TCXO and also has built-in antenna detection for open and short circuit conditions.


The Bison BN1919 module features powerful positioning performance in a 19.0 mm x 10.0 mm x 2.54 mm package. The module's 28 reflow-solderable surface-mount edge castellations provide an interface for your design without the need for costly I/O and RF connectors.

In summary, the BN1919 module has the following key features:

- World-class tracking and acquisition sensitivity
- Incorporates a 3-axis gyro and 3-axis accelerometer
- Supports active and passive antenna designs
- Built-in antenna open and short detection
- 32-tracking channels
- Supports NMEA 0183 protocol
- Carrier board and Starter Kit available
- Pick-and-place assembly, tape and reel packaging, reflow-solderable
- RoHS compliant (lead-free)

Note – *The BN1919 module is not intended to be used as a timing device. This module is primarily used to output a position to a vehicle.*

System block diagram



General recommendations

- The design of the RF transmission line that connects the GNSS antenna to the device is critical to system performance. If the overall RF system is not implemented correctly, the device performance may be degraded.
- The radio frequency (RF) input on the device is a 50 Ω , unbalanced input. There are ground castellations, pins 2 and 4, on both sides of the RF input castellation on pin 3. This RF input must be connected to the output of an LNA that has a GNSS antenna at its input.
- Connections to either the LNA output must be made using a 50 Ω , unbalanced transmission system. This transmission system may take any form, such as microstrip, coaxial, stripline, or any 50 Ω , characteristic impedance unbalanced, low-loss system. It is important to keep any noise sources with frequencies at or near 1575 MHz and 1602 MHz away from the RF input.
- In the printed circuit board (PCB) layout, Trimble requires that you keep the PCB layer on which the device is mounted clear of solder mask and copper (vias or traces) under the module. This is to ensure mating of the castellations between the device and the board to which it is mounted, and to ensure that there is no interference with any feature beneath the device that will cause it to lift during the re-flow solder process.
- The I2C lines are not made available as loading the line can cause the hardware to lock up.

Carrier board

An evaluation board is available for the BN1919 receiver module. The evaluation board allows customers to quickly test and evaluate the performance of the module without the hassle of designing their own PCB to mount the module on. This cuts down on customer development time to market and is cost effective.

The electrical connector to the module uses a 24-pin Hirose part and has a cable assembly available for connection to the receiver.

You can order the carrier board as a separate product, the BN3000. For more information, contact your Trimble sales representative.

Performance Specifications

In this chapter:

- [Global Navigation Satellite System \(GNSS\)](#)
- [Dead reckoning \(DR\)](#)
- [Electrical](#)
- [Environmental](#)

This chapter describes the key performance specifications of the Bison module.

Note – For mechanical specifications, see [Chapter 6, Mechanical Specifications](#).

Global Navigation Satellite System (GNSS)

The Bison module use a single-frequency L1 that can track GPS and GLONASS constellations. However, the solution uses only GPS or GLONASS at any given time.

All performance, accuracy, acquisition and availability requirements assume the following conditions, unless otherwise specified:

- Clear view of the sky
- Multipath-free environment
- ≥ 5 satellites in view
- > 36 CNO signal strengths
- Stable temperature (< 2 °C change per minute)
- < 6 PDOP
- Position change < 800 km since last power down.

Dynamic limits

Characteristic	Limits
Altitude	-1000 m to +18000 m MSL
Velocity ¹	515 m/s
Acceleration ²	4 g
Motion jerk	20 m/sec ³

¹For operational limits set by the USA government.

²The device operates with reduced accuracy when the acceleration exceeds 1 g.

Fix rate

Item	Rate
GNSS fix rate	1 Hz

GNSS accuracy

The entries in this table assume that the unit is producing valid position fixes.

- The accuracy is specified for 3D
- Clear view autonomous GNSS conditions (outdoor, static)
- Velocity accuracies are steady state

Parameter	CEP 50%	CEP 90%
Position, horizontal	< 2 m	< 3.5 m
Position, vertical	< 3 m	< 6 m
Speed accuracy	N/A	0.06 m/s
Heading accuracy	(0.05 m/s) / Speed (1 δ)	
DR accuracy	DR speed accuracy wanted as well, better than 0.5%	

Time to first fix / GNSS acquisition rate

GNSS acquisition time is defined as the time between the unit first being turned on and the moment when valid position fixes are output.

The time to first fix (TTFF) can be affected by any of the following conditions:

- Satellite visibility (fewer than 5 satellites in view with a CNO greater than 40)
- Temperature drift (< 2 °C per minute)
- GNSS receiver powered down for more than one hour (this affects the validity of satellite ephemeris data)
- Backup power not applied during power-down
- The following acquisition times are valid when the unit is at room temperature, has a clear view of the sky with a minimum of 5 satellites in view, and has not been moved more than 800 km since the last position fix.

Type	50% (seconds)	Comment
Reacquisition	≤ 1	Unit has ephemeris, position, and time.
Hot	≤ 1	Unit has ephemeris, position, and time.
Warm	≤ 33	Unit has almanac, position, and time; but no ephemeris.
Cold	≤ 35	Unit has no startup information.

Sensitivity

Scenario	Signal level
Acquire a signal	-148 dBm
Track a signal	-162 dBm

Dead reckoning (DR)

Time to first fix - DR

Parameter	Acquisition time (seconds)
DR - TTFF	< 1

Fix rate

Item	Rate
DR fix rate	5 Hz (default) with 20 Hz option

Electrical

Note – All specifications are over the entire temperature range, -40 °C to +85 °C.

Normal operating conditions

Parameter	Minimum	Typical	Maximum	Units	Conditions
Supply voltage	2.8	3.3	3.6	V DC	
Power consumption		425	480	mW	Track, acquire, excludes external antenna
Supply voltage noise ripple			50	mVpp	From 1 Hz to 1 MHz
Input capacitance on power supply		22		μF	
Additional current for Low Noise Amplifier of active antenna			30	mA	3.0 V miniature GNSS vehicle antenna (at room temperature)
Backup power supply	2.5		3.6	VDC	
Backup current		75		uA	Over temperature range -40 °C to +85 °C

Recommended Power Sequence

Apply power to the XReset (Pin 11) while applying power to V_{CC} (Pin 16). If you do not apply power to the XReset pin at that same time with the V_{CC}, the RTC will be reset upon power-up of the module. You must follow this power-up sequence to prevent the RTC being reset at module power-up. We generally recommend to leave the XReset (Pin 11) as floating.

RF

The following results apply when the Bison receiver is tested with an external signal generator with a noise source connected to the device RF input:

Parameter	Minimum	Typical	Maximum	Units	Conditions
Noise figure		8		dB	
Resistance to broadband noise jamming			20	dB	Jamming to signal ratio at antenna input within input filter bandwidth of 20 MHz; GNSS signal power of ≥ -160 dB
Input impedance		50		Ω	
Resistance to RF burnout			10	dBm	Signals > 100 MHz from L1 at 1 m from the antenna

Sensitivity parameter	Value
Tracking	157 dBm
Acquisition sensitivity	146 dBm

Data I/O

The device interface is CMOS with TTL-compatible levels on TXD and RXD.

Parameter	Min	Typical	Max	Units	Conditions
Data rate		115.2	460.8	kbps	$\pm 3\%$ error rate
Input voltage			0.8	V	Low level at 50 μ A
	2.0			V	High level at 50 μ A
Output voltage			0.2	V	Low level at 4 mA at supply voltage
	2.85			V	High level at 4 mA at supply voltage
Input current	-50		50	μ A	High level
	-50		50	μ A	Low level
Data latency after PPS			100	ms	Delta between PPS and packet transmission

PPS

PPS is present once power is applied to the unit.

Parameter	Min	Typical	Max	Units	Conditions
Timing accuracy (RMS)		60		ns	To UTC time with valid position fixes
Pulse duration	6.0			us	
Rise time of leading edge			25	ns	Rising edge is synchronized to UTC second
Output voltage			0.4	V	Low level (3.3 V)
	2.4				High level (3.3 V)

Recommended GNSS antenna characteristics

Antenna compatibility: Active only.

Power: 3.0 VDC. Power is provided to the antenna through the center conductor of the RF connector.

The antenna current can change, depending on the V_{CC} . It is recommended that you use the NMEA message AN to set the antenna current threshold for the open/short condition. This only applies to the internal antenna open/short detection and is not for external use. For more information, see [Appendix B, NMEA 0183 Protocol](#).

The Bison module has built-in antenna detection for open and short circuit conditions. For more information, see [Appendix B, NMEA 0183 Protocol](#).

The SHORT alert is triggered if more than approximately 100 mA is drawn from the antenna pin and the current is further restricted to a maximum of 33 mA by a current clamp.

Parameter	Min	Typical	Max	Units	Conditions
LNA gain	17		30	dB	
Cable loss			10	dB	
Noise figure			1.5	dB	
Resistance to broadband noise jamming			20	dB	Jammer to signal ratio at antenna input within input filter bandwidth of 20 MHz; GNSS signal power of ≥ -130 dBm

Environmental

Parameter	Min	Typical	Max	Units	Conditions
Operating temperature	-40		+85	°C	
Storage temperature	-55		+105	°C	
Humidity	5		95	%	% R.H. non-condensing at +60 °C.
Thermal shock	-40		+85	°C	The unit will sustain proper operation after a temperature shock of between -40 °C to +85 °C for 100 cycles.
Mechanical shock (non-operational)			75	g	The unit will sustain proper operation after a mechanical shock (drop) test of 75 g /6 msec half-sine.
Mechanical shock (operational)			40	g	The unit will sustain proper operation after a mechanical shock (drop) test of 40 g /6 msec half-sine.
ESD	ESD testing was performed using the IEC1000-4-2 standard. All inputs and outputs are protected to ±500 V ESD level. The RF IN pin is protected up to 1 kV. If a higher level of compliance is required, additional electrostatic and surge protection must be added.				
Vibration	The device shall maintain full performance specifications when the unit is subjected to vibration of up to (5 Hz/0.02 g ² / Hz., 20/0.05, 100/0.05, 800/0.001, 1000/0.001) 4.0 g rms, 15 min each of 3 axis.				

Interface Characteristics

In this chapter:

- [Pin-out assignments](#)
- [Detailed pin description](#)

This chapter describes the key mechanical specifications of the Bison module.

Pin-out assignments

<i>GND</i>	1	Bison DR + GNSS	28	<i>GND</i>
<i>GND</i>	2		27	<i>Reserved</i>
<i>RF In</i>	3		26	<i>FWD/REV</i>
<i>GND</i>	4		25	<i>Speed signal input</i>
<i>Reserved</i>	5		24	<i>UART TXD</i>
<i>VBACKUP</i>	6		23	<i>Reserved</i>
<i>Antenna OPEN</i>	7		22	<i>Reserved</i>
<i>Antenna SHORT</i>	8		21	<i>Reserved</i>
<i>Reserved</i>	9		20	<i>UART RXD</i>
<i>Reserved</i>	10		19	<i>PPS</i>
<i>XRESET</i>	11		18	<i>Reserved</i>
<i>Reserved</i>	12		17	<i>Reserved</i>
<i>Reserved</i>	13		16	<i>VCC</i>
<i>GND</i>	14		15	<i>GND</i>

Pin number	Name	Pin number	Name
1	Ground	28	Ground
2	Ground	27	Reserved
3	RF_IN	26	FWD/REV direction (input)
4	Ground	25	Speed signal input
5	Reserved	24	UART TXD (output)
6	Vbackup	23	Reserved
7	Antenna OPEN	22	Reserved
8	Antenna SHORT	21	Reserved
9	Reserved	20	UART RXD (input)
10	Reserved	19	PPS (output)
11	XRESET (external reset)	18	Reserved
12	Reserved	17	Reserved
13	Reserved	16	VCC
14	Ground	15	Ground

Detailed pin description

RFIN


The RF input pin is the 50 Ω unbalanced GNSS RF input, and can be used with active antennas.

OPEN/SHORT

The GNSS has built-in antenna detection for open and short-circuit conditions. By default, the open and short alerts are turned on. For more information, see [Appendix B, NMEA 0183 Protocol](#).

The SHORT alert is triggered if more than approximately 65 mA is drawn from the antenna pin and the current is further restricted to a maximum of 130 mA by a current clamp.

The diagram shows the active antenna drawing current through a 10 Ω sense resistor, supplied by a voltage regulator, supplied by VCC internally. As a result, there will be an associated voltage drop as the current increases:



Note – This diagram is not a circuit diagram—it is a representation of how the open/short detection scheme works.

Refer to the application designs for examples of antenna power circuits.

The antenna OPEN and antenna SHORT pins are intended to be used as part of an antenna detection system when the external antenna power is not handled by the Bison module. For example, if the external antenna uses a 5.0 V supply, the Bison module cannot be used to power the antenna. For example circuits that you can use with an externally powered antenna, see [Appendix C, Reference Circuit](#).

If the OPEN pin is not used, it should be pulled down to GND through a 10 k Ω resistor.

If the SHORT pin is not used, it should be pulled up to VCC through a 10 k Ω resistor. The SHORT pin is pulsed high for 25 ms every second to check the antenna operation.

XRESET

Use this logic-level, active low input to issue a reset to the module. It can be connected to external logic or to a processor to issue a reset instruction. To reset the module, drive this pin to logic level “0” or “Low” for at least 100 microseconds, and then either release this signal or drive it back high. This pin has an internal 4.7 k Ω pull-up resistor; if this pin is not used, leave it disconnected.

VCC

This is the primary voltage supply pin for the module.

RXD

This logic level input is the serial port receive line (data input to the module). Leave disconnected if not used.

TXD

This logic level output is the serial port transmit line (data output from the module). Leave disconnected if not used.

Speed signal input sensor

2.8 V LVTTTL, 3.3 V to 5 V tolerable. Maximum speed pulse frequency is 3 kHz.

FWD/REV direction switch

2.8 V TTL, 3.3 V to 5 V tolerable. The Bison receiver can work with both High (FWD) and Low (FWD) conventions. The Bison module will determine the sign of the direction switch automatically when the device is first used.

RESERVED

There are several reserved pins. **Do not** connect these pins.

Note – *Do not place solder mask, copper traces, vias, or other conductive elements under the module when designing the Bison module into your system.*

Orientation and Calibration

In this chapter:


- [General Bison module coordinate system](#)
- [Dead-reckoning \(DR\) calibration](#)

The Bison module must know its mounting orientation for proper operation. If the mounting orientation is known, users can program the orientation angles directly into the module. The receiver will immediately start in DR mode.

General Bison module coordinate system

Bison follows this general vehicle coordinate system, but the layout of the sensors is different from previous modules, such as Aardvark or Numbat. In addition, Bison introduces a new feature called G-Sensor that uses an onboard accelerometer to enable measurement of changes in altitude during real-time driving. Both the gyro and accel need to have mounting angles, but their coordinate frames are different.

General vehicle coordinate system




Where:

- Vx: Forward and on the longitudinal plane of symmetry
- Vy: Lateral out the left side of the automotive vehicle
- Vz: Upward with respect to the automotive vehicle
- Roll: A rotation around the Vx axis. Positive roll means the left side of the vehicle lifts.
- Pitch: A rotation around the Vy axis. Positive pitch means the front of the vehicle goes down.
- Yaw: A rotation around the Vz axis. Positive yaw means the vehicle turns left.
- Heading: Heading follows the compass convention with 0° at North, 90° at East, 180° at South, 270° at West. A positive change in heading means the car is turning right.
- Forward/Reverse: This always refers to direction along the Vx axis. Forward is motion in the direction the front of the car is pointing, reverse is motion in the direction the rear of the car is pointing.

The BN1919 module has a three-axis gyro and a sophisticated calibration algorithm that allows you to mount the module in any orientation relative to the vehicle. For example, the module can be mounted flat, tilted at an angle, upside-down, or on its side.


BN1919 Gyro coordinate system



This is a right-handed coordinate system, and rotation angles are defined by a right-hand rule around these axes:

- Roll: A rotation around the Gx axis. Positive roll means the Gy axis lifts.
- Pitch: A rotation around the Gy axis. Positive pitch means the Gx axis goes down.
- Yaw: A rotation around the Gz axis. Positive yaw means the Gx and Gy axes turn left.

Bison Accel coordinate system



This is a right-handed coordinate system, and rotation angles are defined by a right-hand rule around these axes:


- Roll: A rotation around the Ax axis. Positive roll means the Ay axis lifts.
- Pitch: A rotation around the Ay axis. Positive pitch means the Ax axis goes down.
- Yaw: A rotation around the Az axis. Positive yaw means the Ax and Ay axes turn left.

Gyro mounting angle

The BN1919 can be mounted in any angle in a vehicle. The on-board 3-axis gyroscope in the module determines how the module is mounted. The user can set up the actual installed mounting angle of the module in one of the following ways:

User-defined configuration


If the exact angle is known using mechanical drawings, the user can enter this directly as a configuration in Trimble Studio in the *Mounting Angle* screen. This is useful if the receiver is being installed on a single model of vehicle with a defined mounting scheme:



Calibrate and match to profile

If the Bison module will be used in multiple installations, where the installation angles are known for each installation, the module can select from preset profiles that are programmed into it. The Aardvark module will select the set that best matches the actual measured orientation—it will use measurements made while the vehicle is moving to "snap" to one of the orientations. Once the initial calibration has been completed successfully, the Bison module uses this set of orientation angles for all future calculations. Until it has been calibrated, the module operates in GNSS-only mode.

Users can use HIPPO protocol 0x70-60 for the mounting angle calibration, see [0x70-60: Mounting Angle Calibration](#), page 65.




Self-calibration configuration

The Bison module can also be mounted in any arbitrary orientation and set to calibrate itself by using measurements made while the vehicle is moving to determine its actual orientation angles. This set of maneuvers will include a certain amount of time standing still and a certain number of right angle turns. Once the initial calibration has been completed successfully, the module uses this set of orientation angles for all future calculations.

The set of maneuvers that needs to be carried out for the gyro to determine its mounting angle should meet the following requirements:

- Done in open sky view.
- Performed on a flat road.
- Complete a series of approximately 10 right angle (90°) turns and 10 left angle (90°) turns.
- Forward speed should be greater than 30 km/hr or 15 mph.
- Each turn should be completed in less than five second.

- In between the turns there should be periods of rest for vehicle. The vehicle should come to a complete stop.



The Calibrate Only option is a longer process than the other two options that can be used to enter the mounting angle of the module.

Factory-default configuration

Note – If required, you can command the Bison module to return to the factory-default mounting angle.

To monitor the mounting angle calibration status, use HIPPO 0x70-60.


To configure mounting angles, users can use HIPPO 0x70-61.

If the Bison module finds that its current orientation does not match the orientation found during calibration, it will re-enter calibration mode.

Accelerometer mounting angle

The Bison DR + GNSS module incorporates a 3-axis accelerometer to measure the forward acceleration in combination with the DR and GNSS position and velocity data to provide relative changes in altitude and changes in the slope of the road.

In order for the accelerometer to provide proper measurements, the module needs to know the orientation of the accelerometer within 3 degrees in all three axes, (roll, pitch, and yaw). Once this is determined, the values can be entered into the following fields:



Calculating the gyro orientation vector

The Bison module (P/N 99988-XX) uses a three-axis gyro to measure the complete motion of the vehicle in calculating the dead reckoning solution. It needs to know its orientation relative to the vehicle to make the correct translation between the measured motion and the vehicle's actual motion on the ground. The user can input a vector (a set of three numbers) that represents the orientation of the module relative to the vehicle.

To calculate the orientation vector, the mounting angles for the Bison module must be known, specifically the pitch and roll—the yaw (the orientation relative to forward) is not used.

To understand the pitch and roll angles, see the diagrams on the previous page that show the coordinate systems of the vehicle and the Bison module—the directions of the arrows in the diagrams define the positive axis of the coordinate system. Rotations are defined using the "right-hand rule." This means that a positive rotation around the Vy axis will be down at the nose of the vehicle; a positive rotation around the Vx axis will bring the left side up, the right side down. A rotation around Vy is pitch; a rotation around Vx is roll. The order of rotations matter when calculating the vectors.


The Bison module's roll and pitch angles are defined as the combination of rotations of pitch then roll that brings the Bison from level to the actual mounting angle.

Once the angles are known, the vectors are calculated as follows:

$$U = [U_x \ U_y \ U_z] = [-\sin(\text{pitch}) \ \cos(\text{pitch}) * \sin(\text{roll}) \ \cos(\text{pitch}) * \cos(\text{roll})]$$

Note – The vector is a unit vector, where $U_x^2 + U_y^2 + U_z^2 = 1$. This is useful when checking your calculation.

You can use the Trimble Studio software to enter this vector into the device; alternatively use HIPPO packet 0x70-61. To set the "up" vector, use the values calculated as $U = [U_x \ U_y \ U_z]$ above. Ideally, the left/forward vectors should match how the module is physically mounted in the vehicle. The following screen shows examples of different XYZ and roll pitch and yaw values:



Note – Programming the module with the orientation (0, 0, 0) will not affect the current firmware.

You can set and store multiple profiles in the Bison module. This is useful when you program the module at one location, but then install it on multiple vehicles with different mounting angles as you can preset a number of possible mounting angles for the unit.

Use the "set" format of HIPPO packet 0x70-61 to enter the mounting orientation. The "up" vector components are calculated as shown above. However, this command will only program the module to one set orientation. This packet will command the Bison module to use a specific angle, to commence a full self-calibration, or to commence a matching calibration where the module "snaps" to one of the profiles in the set of possible mounting angles defined in the 0x70-61 packet.

Note – If the command 0x70-61 is used to program the UP vector (0,0,1) as the only profile, the firmware will not use this vector until it completes the self-calibration and finds the self-calibrated vector matches (0,0,1). This differs from 0x70-60. If 0x70-60 is used to program UP vector (0, 0, 1), the firmware will use this vector as it is and will never start the self-calibration process.

Dead-reckoning (DR) calibration

Note – Users can only proceed with the DR calibration once the mounting angle of the module has been determined. If they do not do this, the DR performance will not meet specification.

Purpose of dead-reckoning calibration

Users must calibrate the Bison DR + GNSS receiver after installation to ensure an accurate output from the receiver. The calibration will measure some of the characteristics that are specific to the vehicle installation, and is done automatically when the unit is first installed.

Before the module is calibrated, it will provide a GNSS position once. After calibration, the receiver will operate in DR+GNSS position. It shows a status flag to inform customers of the mode in which the unit is operating.

To calibrate the receiver, you must drive a set of maneuvers that will give the receiver visibility into the following parameters:

- Distance per pulse (DPP)—this calibrates the odometer output to relate output pulses to meters traveled. It is a combination of the actual vehicle Speed signal output characteristics and the tire size and pressure.
- Direction switch—the receiver determines whether the output of the direction switch is high or low when traveling forward.
- Gyro offset (Zero Rate Output [ZRO])—this is the output of the on-board gyro when the vehicle is not moving.
- Gyro scale factor (GSF)—this is the relationship between the output of the gyro and the actual turning rate.

General calibration requirements

DR calibration involves the parameters DPP, direction switch, ZRO, and GSF—they are largely calibrated in parallel.

To do this, you can drive a set of 10 or more 90° turns (both right hand and left hand) with a forward speed greater than 30 km/hr (18 mph) and certain speed before the turns. Separate the turns with the some intervals of the vehicle at a standstill. For example, if the vehicle makes four right hand turns, stop for 5 seconds before starting again. The calibration drive must be done on a flat road and in open sky conditions that provides good GNSS visibility.

During this time:

- *DPP* calibrates at any time that there is a good GNSS track.
- The *direction turn* switch calibrates during the first motion.
- *ZRO* is calibrated at any time that the vehicle is not moving.
- *GSF* is calibrated during turns.

You only need to complete the initial calibration once. After the initial calibration, the receiver will continually update the calibration whenever it has appropriate data with good GNSS tracking.

Software

In this chapter:

- [Port configuration](#)
- [Tools](#)
- [Software](#)
- [Interfaces](#)
- [Communication protocols](#)

This chapter describes the software used with the Bison receiver.

Port configuration

Input	Setup	Output	Notes
HIPPO	115200-8-NONE-1 (default)	HIPPO / NMEA	115200-8-NONE-1 From here, you can change to other baud rates.

Tools

Parameter	Description
Monitoring, configuring, exercising functionalities	The Trimble Studio software program can monitor, configure, and exercise the device functions.
Updating application firmware	The Trimble Studio program supports updating the application firmware of the device. You can download the Trimble Studio software from the Support section of the Trimble embedded products website. Go to www.trimble.com/embeddedsystems

Software

Features

Parameter	Description
DR reporting frequency	Provide DR positioning data at a programmable frequency of 5 Hz to 20 Hz. Note – Higher frequencies will require higher baud rates.
DR position reporting	The following DR position data is provided: <ul style="list-style-type: none"> Position as WGS84 latitude ($-\pi/2$rad, $\pi/2$rad), longitude ($-\pi$, $+\pi$ rad) and altitude (m) Position accuracy (m) Position status (invalid, valid)
DR heading reporting	The heading is always the direction the front of the car points to (north is 0 radians; clockwise is positive increasing). The following DR heading information is provided: <ul style="list-style-type: none"> Heading (0 rad, 2π rad) Heading accuracy (rad) Heading status (invalid, valid)

Parameter	Description
DR speed reporting	The following DR speed data is provided: <ul style="list-style-type: none"> • Speed (m/s) • Speed accuracy approximation, derived from Kalman filter parameters (m/s) • The direction switch status (invalid, forward, backward) • Speed status (invalid, valid) • Motion indicator (invalid, motion, no motion)
DR delta distance reporting	The following DR delta distance data is provided: <ul style="list-style-type: none"> • Delta distance (m) since previous timestamp (not based on the distance between 2 successive positions) • Delta distance accuracy approximation, derived from Kalman filter parameters (m/s) • Delta distance status (invalid, valid) • Always a positive value (total distance forward - total distance backward) since last report. Direction status indicates if the direction traveled is forward or backward.
DR delta heading reporting	The following DR delta heading data is provided: <ul style="list-style-type: none"> • Delta heading (centidegrees) since the previous timestamp • Delta heading accuracy approximation, derived from Kalman filter parameters (centidegrees) • Delta heading status (invalid, valid)
GNSS reporting frequency	Provide GNSS positioning data at a programmable frequency of 0 Hz or 1 Hz.
GNSS position reporting	The following GNSS position data is provided: <ul style="list-style-type: none"> • Position as WGS84 latitude ($-\pi/2\text{rad}$, $\pi/2\text{rad}$), longitude ($-\pi$, $+\pi$ rad) and altitude (m) • GNSS status (no SVs, tracking but no position, 2D, 3D) • Position accuracy (m)
GNSS heading reporting	The heading is always the direction where the front of the car is pointing (north is 0 radians, clockwise is positive increasing). The following GNSS heading data is provided: <ul style="list-style-type: none"> • Heading (0 rad, 2π rad) • Heading accuracy (rad) • Heading status (invalid, valid)
GNSS speed reporting	The following GNSS speed data is provided: <ul style="list-style-type: none"> • Speed (m/s) • Speed status (invalid, valid) • Speed accuracy (m/s)

Parameter	Description
System information	The following information is provided on request and when power is turned on: <ul style="list-style-type: none"> • GNSS receiver connected/responding status • Battery backup (error) status • Antenna feed line error (open/short) status • Almanac status • DR software version • DR software date • GNSS software version • GNSS software date • Flash data (product name, serial number, and date of manufacture) • Sensor status indication (speed signal input and gyro detected)
GNSS information	The following GNSS data is provided: <ul style="list-style-type: none"> • IDs of tracked satellites (#) • SNRs of tracked satellites (dB-Hz) • Number of visible (tracking list) satellites • Azimuth of each visible satellite (°) • Elevation of each visible satellite (°) • DOP values • UTC time (yyyy/mm/dd/hh/mm/ss) • GNSS time • GNSS status
Map matching	The device uses map positions and heading, received through messages, to improve positioning data accuracy.
BBRAM	The device keeps positioning data, sensor calibration data and GNSS almanac and ephemeris data during power off with backup power available. This includes a "no speed signal input mode" indicator. The saved values are used when the system is restarted.
RTC	The RTC is kept alive when backup power is present.
Self-calibration	The uncalibrated device can calibrate itself (for example, provide valid positioning data) from the first GNSS 2D measurement onward. The device is fully calibrated when: <ul style="list-style-type: none"> • GNSS is navigating uninterrupted during 60 seconds (DPP) • Speed during these 60 seconds is > 8 m/s (DPP) • Gyro sensitivity after 100 right hand turns (GSF) <p>Note – <i>The device must be calibrated on horizontal roads. The position is valid after the first 3D position fix.</i></p>
Direction switch	The device automatically determines the direction switch logic level.
Non-volatile memory (NVRAM)	The device supports a message to perform a back-up of DR calibration and user configuration data into Flash/NVRAM.
Calibration data	The device supports messages to send and receive positioning and sensor calibration data that needs to be preserved during power loss.

Parameter	Description
Raw sensor diagnostics	<p>The device provides the following raw sensor data with programmable update frequencies of 5 Hz or 10 Hz (HIPPO packet 0x30-02: Fast Fix with Raw DR Data Message):</p> <ul style="list-style-type: none"> • Number of actual speed sensor pulses • Actual direction switch value • Gyro output value
Calibration data diagnostics	<p>The device provides the following calibration data upon request (HIPPO packet 0x36: DR Calibration Messages):</p> <ul style="list-style-type: none"> • Zero Rate Output (ZRO) • Sensitivity (mV / ° / s) • Gyro calibration status (ZRO Calibrated Y/N, Sensitivity Calibrated Y/N) • Direction switch status (Calibrated, Y/N) • Direction switch value (Forward or Reverse) • Distance Per Pulse (DPP) • Speed sensor calibration status (Calibrated, Y/N)
Sensor interface test	<p>The device provides the following self-test functions when turned on. The results of the test are reported to the host upon query.</p> <ul style="list-style-type: none"> • ADC/Gyro—read gyro output level on start-up and verify its validity.
Power On self test	<p>The following diagnostic self-tests are performed when the device is turned on:</p> <ul style="list-style-type: none"> • FLASH ROM checksum • RTC validation • RAM read/write test
Run-time positioning diagnostics	<p>The device can constantly verify the performance of the GNSS against the peripheral DR inputs and vice versa during normal operation. If any instance of non-conformance is detected, the device logs the non-conformance event in an error log. The following instances of non-conformance are identified:</p> <ul style="list-style-type: none"> • A positioning process is not active under normal conditions. • Gyro readings do not stay within specification. • No speed signal input data is received during a period when GNSS is detecting movement. • Excessive speed signal input data is received for a long period of time. • Reverse signal is opposite to the direction determined by GNSS. When battery back up data is not available, the reverse signal must be calibrated before an error can be reported. • Large or numerous jumps occur as a result of differences between DR positions and GNSS Positions. • Oscillator values are not within specification.

Parameter	Description
Error/event log	<p>The device has an error/event log in non-volatile memory that records all system events and errors. For more information, refer to Trimble document P/N 45294-XX-SP.</p> <p>All events reported to the log have the following format:</p> <ul style="list-style-type: none"> • Event identification • Time tag (yymmddhhmmss) <p>Writing to the log initiates an error message to the host using HIPPO packet 0x14-01: Soft Event Log Report. The log maintains the last 128 events that occur in the system. Any prior events are lost.</p> <p>The log queue is maintained in non-volatile memory.</p> <p>Access to the log is available through HIPPO packet 0x14-01: Soft Event Log Report.</p>
DR calibration and user configuration	The DR calibration and user configuration are saved to non-volatile memory when receiving a "graceful shutdown" HIPPO packet.
TCXO aiding	The value of the TCXO offset is stored in non-volatile memory during production testing. It improves GNSS acquisition and tracking, provided that the GNSS module supports accepting externally-provided TCXO offset.

Performance requirements

Parameter	Description
DR position accuracy	<p>Overall position accuracy with GNSS is better than or equal to the GNSS position accuracy, see GNSS accuracy, page 14.</p> <p>Position accuracy without GNSS shall be within the limits of the individual heading and speed accuracy defined in this section.</p>
DR heading accuracy	<p>With use of a gyro, the heading accuracy, when GNSS is available, is:</p> <ul style="list-style-type: none"> • Within 2 degrees when speed > 1 m/s or speed = 0 m/s. • Within 10 degrees when: <ul style="list-style-type: none"> • speed < 1 m/s; and • speed ≠ 0 m/s; and • within gyro-drift of the actual used gyro when GNSS is not available (2 degrees + heading difference caused by gyro-drift). <p>Without use of a gyro (only in 'GNSS only' applications and in non-calibrated positioning modules), the heading accuracy is better than or equal to GNSS heading accuracy.</p>
DR speed accuracy	<p>With use of a speed sensor, the speed accuracy is better than 0.2 m/s. at speeds above 0.5 m/s. Without use of a speed sensor (only in 'GNSS only' applications and in non-calibrated positioning modules), the speed accuracy is better than or equal to the GNSS speed accuracy.</p> <p>Motion is defined as "speed is above lowest detectable speed". Speeds above 0.5 m/s have this motion indication.</p>

Parameter	Description
DR delta distance accuracy	With use of a speed sensor, the delta distance accuracy is better than 0.2 m/s. at speeds above 0.5 m/s. Without use of a speed sensor (only in 'GNSS only' applications and in non-calibrated positioning module), the delta distance accuracy is better than or equal to GNSS speed accuracy.
DR delta heading accuracy	With use of a gyro, the delta heading accuracy is better than 1 degree. Without the use of the gyro (only in non-calibrated positioning module), the delta heading accuracy is better than or equal to the GNSS delta heading accuracy.
GNSS position accuracy	See GNSS accuracy, page 14.
GNSS speed accuracy	See GNSS accuracy, page 14.
GNSS heading accuracy	See GNSS accuracy, page 14.

Timing or latency requirements

Parameter	Description
DR packet latency	A max delay of 100 msec from the start of DR data collection to the start of DR packet transmission.

Upgrade requirements

Parameter	Description
Application firmware	You can upgrade the application firmware in the field using the Trimble Studio software or any user application implementing a firmware upgrade protocol.

Interfaces

Parameter	Description
ADC	The ADC interface for the analog gyro (digital gyros perform internal ADC operations)
RTC	The real-time clock interface for maintaining time when the device is on the battery power with the main power switched off
NVRAM	The non-volatile memory interface for storing DR calibration and user configuration
Antenna	The antenna short/open detection interface
UART	The serial I/O interface for communication protocols
Speed signal input	The speed signal input interface for measuring the vehicle speed
Direction switch	The direction switch interface

Communication protocols

Parameter	Description
HIPPO	The HIPPO protocol interface is implemented. See Appendix A, HIPPO Protocol for supported messages.
NMEA	The NMEA protocol interface is implemented. See Appendix B, NMEA 0183 Protocol for supported messages.

Note – Both protocols are output through the serial port. This has a switch feature that enables you to switch off the auto-output of either the HIPPO or NMEA protocol.

Mechanical Specifications

In this chapter:


- [Form factor](#)
- [Mechanical drawing](#)
- [Layout](#)

This chapter describes the key mechanical specifications of the Bison module.


Form factor

Parameter	Description
Size	19 mm x 19 mm x 3.05 mm without RF connector.
Mounting	For SMT operation, see Mechanical drawing, page 42 .
Metal shield	Covers the entire module for handling, ESD protection, and preventing mechanical damage.

Mechanical drawing



Outline Drawing



Outline Dimensions ()


	Inch	mm																					
A	0.75	19.00	B	0.049	1.25	C	0.256	D	0.197	E	0.295	F	0.050	G	0.120	H	0.045	I	0.030	J	0.050	K	0.050
	19.00			1.25			6.50		5.00			7.50		1.27		3.05		1.14		0.76		1.27	

Layout

This section provides the suggestions for the solder mask for the BN1919 module.


Note – These are Trimble recommendations only for customer designs.

Suggested customer solder mask




Note – No solder mask or copper traces or vias or conductive elements under the unit.

Suggested customer pad pattern



Note – No solder mask or copper traces or vias or conductive elements under the unit.

Suggested customer paste pattern



Storage and Handling

In this chapter:

- Moisture
- Baking procedure
- Soldering paste
- Solder reflow
- Recommended solder profile
- Optical inspection
- Cleaning
- Repeated wave soldering
- Wave soldering
- Hand soldering
- Rework
- Conformal coating
- Metal shield grounding
- PCB fabrication

Moisture

Moisture Sensitivity Level

The Moisture Sensitivity Level (MSL) relates to the storage and handling requirements. The 19x9 modules are rated at MSL level 4.

Moisture precondition

You must take precautions to minimize the effects of the reflow thermal stress on the component. Plastic molding components for integrated circuit encapsulation are hygroscopic and absorb moisture, dependent on the time and the environment.

Absorbed moisture vaporizes during the rapid heating of the solder reflow process, generating pressure on all the interface areas in the package, which is followed by swelling, delamination, and even cracking the plastic. Components that do not exhibit external cracking can have internal delamination or cracking which affects the yield and reliability.

Baking procedure

If baking is necessary, Trimble recommends baking in a nitrogen purge oven.

Temperature: 125 °C

Duration: 24 hours

After baking: Store in a nitrogen-purged cabinet or dry box to prevent absorption of moisture.



CAUTION – Repeated the baking process will reduce the solderability.



CAUTION – Do not bake the units within the tape and reel packaging.

Soldering paste

The device itself is not hermetically sealed. It is strongly recommended that you use the "No Clean" soldering paste and process. The castellation solder pads on this module are plated with silver plating. It is recommended that you use Type 3 or above soldering paste to maximize the solder volume. The following is an example of the solder paste that you can use:

Solder paste: SAC405

Alloy composition: Sn95.5Ag4Cu.5 95.5% Tin/ 4% Silver/ 0.5% Copper

Liquidus temperature: 217 °C

Stencil thickness: 6.0 mil (0.0006")

Stencil opening requires 6-mil toe over paste in the X and Y directions.

Refer to the instructions provided by the solder paste manufacturer and the assembly process for the approved procedures.

Solder reflow

A hot-air convection oven is strongly recommended for solder reflow. For the lead-free solder reflow, we recommend using a nitrogen-purged oven to increase the solder wetting. Refer to IPC-610D for the lead-free solder surface appearance.



CAUTION – Follow the thermal reflow guidelines from IPC-JEDEC J-STD-020C.

The size of this module is 957 mm³. According to J-STD-020C, the peak component temperature during reflow is 245 °C.

Recommended solder profile

You must carefully select the final soldering thermal profile. The thermal profile depends on the choice of the solder paste, thickness and color of the carrier board, heat transfer, and size of the panelization.



CAUTION – For a double-sided surface-mount carrier board, place the unit on the secondary side to prevent the module or its shield falling off during reflow.

Optical inspection

Once you have soldered the device's GNSS module to the carrier board, follow the IPC-610 specification and visually inspect the module under a 3x magnification lens for the following:

- Verify that each pin is correctly aligned and centered over the solder pads with the mount pad.
- Verify that the pads are correctly soldered.
- Verify that no solder is bridged to the adjacent pads, and X-ray the bottom pad if necessary.

Cleaning

When the device is attached to the user board, a cleaning process voids the warranty. The silver plated device may discolor with cleaning agent or chlorinated faucet water. Any other form of cleaning solder residual may cause permanent damage and voids the warranty.

To eliminate the cleaning step after the soldering process, use a "no-clean" solder paste.

Repeated wave soldering

Trimble recommends only a single reflow soldering process for boards integrating the 19x19 module.

If you need to go through a second reflow, mount the module during the second cycle to prevent it falling off the board due to its large weight scale relative to other components.

Note – Repeat reflow soldering processes and soldering the module upside down are not recommended.

Wave soldering

The device cannot soak in the solder pot. If the carrier board is mixed with through-hole components with surface mount devices, it can process with one single lead-free wave process. The temperature of the unit will depend on the size and the thickness of the board. We recommend measuring the temperature on the module and keeping it under 180 °C.

Hand soldering

For the lead-free device, we recommend using a lead-free solder core, such as SAC405 Sn95.5/Ag4/Cu0.5. When soldering the module by hand, keep the soldering iron below 260 °C while following IPC recommendations.

Rework

The device can withstand one rework cycle. The module can heat up to the reflow temperature to precede the rework. ***You should never remove the metal shield and rework the module itself, as this will void the warranty.***

Conformal coating

Conformal coating on the device is not allowed. If used, the warranty will be voided.

Metal shield grounding

This module is designed with numerous ground pins that provide the best immunity to the EMI and noise shielding. Any alteration in adding ground wires to the metal shield will be done at your own risk.

PCB fabrication

Number	Parameter	Description
1	Metal	Copper
2	Solder mask	TAIYO PSR 4000 MH
3	Silk screen legend	Any Non-conductive
4	Surface finish	ENIG 10 μ " \pm 4"
5	Laminate material	Isola PCL FR370HR
6	Panelization	The PCB shall be pre-routed with mouse bite tabs for depanelizing.

HIPPO Protocol

In this appendix:

- [Soft event and fatal error logging and reporting](#)
- [Available HIPPO messages](#)
- [System class messages](#)
- [HIPPO protocol rules](#)
- [Command messages](#)
- [Report class](#)
- [Event log queue](#)

This chapter describes the HIPPO protocol.

The Bison firmware implements a sub-set of the HIPPO messages described in the HIPPO Protocol Specification.

Soft event and fatal error logging and reporting

The Bison module supports the soft event and fatal error logging and reporting described in the *HIPPO Protocol Specification*. While both HIPPO messages for soft events (0x14-01) and fatal errors (0x14-02) are supported, only soft events are actually implemented, as shown below. No fatal errors are currently implemented. The HIPPO specification lists all possible event codes supported by different products; the following table lists only soft events supported by the Bison module:

ID	Name	Description	Type ¹
0x01	LOG_SOFT_RESET	System performed a warm reset.	S
0x02	LOG_COLD_RESET	System performed a cold reset.	S
0x03	LOG_FACTORY_RESET	System cleared flash and RAM and then reset.	S
0x05	LOG_BBRAM_INVALID	Invalid BBRAM detected on startup.	S
0x06	LOG_GRACEFUL_SHUTDOWN	System performed a graceful shutdown.	S
0x10	LOG_TEST_PASSED	System passed all diagnostic tests.	S
0x11	LOG_TEST_START	Begin system test.	S
0x12	LOG_TEST_END	Indicates the end of a test event.	S
0x20	LOG_FORCE_TO_MONITOR	Force to monitor command executed.	S
0x40	LOG_NAV_FIRST_FIX	GNSS receives the first fix on start up.	S
0x42	LOG_POSITION_SNAP	Output solution snapped to DR-GNSS.	S
0x43	LOG_POSITION_RECOVERY	Position recovery, snapped to GNSS.	S
0x44	LOG_HEADING_RECOVERY	Heading recovery, snapped to GNSS.	S
0x45	LOG_DPP_RECOVERY	DPP recovery, snapped to GNSS.	S
0x46	LOG_ZRO_RECOVERY	ZRO recovery.	S
0x50	LOG_NAV_USER_TIME	User entered time on startup.	S
0x51	LOG_NAV_USER_POS	User entered position on startup.	S
0x62	LOG_GYRO_ANOMALY	Gyro readings not within specification.	C
0x63	LOG_NO_TACHO_WHILE_MOVING	No speed signal input when GNSS detects motion.	C
0x65	LOG_REVERSE_GNSS_DISAGREE	Reverse signal opposite to GNSS.	C
0x66	LOG_LARGE_JUMP	Large jump at power-up.	C
0x67	LOG_OSCILLATOR_ANOMALY	Oscillator values out of specification.	C
0x70	LOG_ANTENNA_OPEN	Antenna open detected.	C
0x71	LOG_ANTENNA_SHORT	Antenna short detected.	C
0x74	LOG_ERR_GYRO	Gyro failed on startup.	C
0x75	LOG_ERR_ADC	ADC failed on self-test.	C

¹Indicates whether the event is a single (S) or a continuous (C) event. Refer to the *HIPPO Protocol Specification* for details.

Available HIPPO messages

The following table lists HIPPO messages implemented and available in the Bison firmware. It also indicates whether a particular message can be queried (Q) or set (S). Messages that can be neither queried nor set are output automatically. For such messages, the output frequency is shown. For detailed information, refer to the *HIPPO Protocol Specification*.

Code	Sub-Code	Indexed By	Message	Q	S	Output Frequency
0x31	0x01		GNSS fix	Q		
0x31	0x02		GNSS fix (extended)	Q		1 Hz
0x32	0x01		UTC time and constellation summary	Q		1 Hz
0x33	0x01	Channel	GNSS channel measurement short status	Q		1 Hz
0x36	0x07		DPP calibration	Q		
0x70	0x0D		BBRAM data			Startup
0x70	0x0E		Startup time			Startup
0x70	0x12		Temperature data	Q		1 Hz
0x70	0x13		DR sensor data (Gyro, Speed Sensor, Direction Switch, PPS)			5 Hz
0x70	0x14		Accelerometer Sensor Data			5/10 Hz
0x70	0x20		GNSS raw measurement group data			1 Hz
0x70	0x21	Channel	GNSS raw measurement channel data			1 Hz
0x70	0x22		GNSS fix data			1 Hz
0x70	0x24		Used SVs information			1 Hz
0x70	0x26		Ionosphere parameters			Event
0x70	0x27		Map-matching data input		S	
0x70	0x28	SV PRN	Ephemeris and subframe 1 data			Event
0x70	0x30		DR KF output (calibration) data			1 Hz
0x70	0x31		GNSS KF output data			1 Hz
0x70	0x32		DR fix data			5 Hz
0x70	0x60		Mounting angle calibration	Q	S	Startup
0x70	0x61		Mounting angle profiles	Q	S	
0x70	0x7F		Toggle diagnostic output	Q	S	

System class messages

The Bison firmware also supports the following system class messages. Refer to the HIPPO specification for a description of different HIPPO message classes and formatting specifics.

Message Field	Type	Value	Meaning
Code	U8	0x03	
Subcode	U8	0x01	Reset
		0x02	Clear RAM, reset
		0x03	Force to Monitor Mode / Bootloader
		0x05	Clear ephemeris, reset
		0x07	Clear flash data and BBRAM, reset
		0x09	Write BBRAM to flash, reset (graceful)

HIPPO protocol rules

The HIPPO message structure is derived from the Trimble Standard Interface Protocol (TSIP) message structure. Both are binary protocols with pre-parsers that "unstuff" the bytes in the serial stream (S-bytes) to create packets of message bytes (M-bytes). Both are asynchronous protocols, allowing the host and module to send multiple commands without waiting for the completion of the previous command.

However, the HIPPO design offers easier and more reliable parsing. In contrast to TSIP, which requires a small state machine after the pre-parser to determine the start and end of the message packet, HIPPO uses unique S-bytes to identify the start and end before the pre-parser. The HIPPO message structure currently uses three control characters:

- 0x80: HIPPO Control Character (HCC)
- 0x81: Start of Message (SOM)
- 0x82: End of Message (EOM)

HIPPO also reserves five other bytes (0x83 – 0x87) for future use as control characters.⁶ TSIP only uses two control characters (DLE and ETX). Although HIPPO has a higher control character overhead (3% versus 0.4% for TSIP), the parser design is much simpler.

Because the HIP module is designed to send messages at 10 Hz, the message length has been limited to 128 bytes to ensure that two messages can be transmitted in each 100 ms cycle.

Number representations use IEEE formats, and are sent with the least significant byte first (Intel specification or "little endian").

The module acknowledges all commands with a reply message after parsing and processing are complete. "Completion" is the point at which all immediate actions in the protocol layer are complete. These actions include replying to queries, setting global variables, flags, or semaphores, and sending messages to other tasks. If the command is a successful query for a single report, the report response itself is the acknowledgment response; otherwise, the module sends an acknowledgment response packet 0x10 to the host.

There are two general types of messages: report messages and command messages.

General message structure rules

The byte SOM only occurs as an S-byte (in the serial stream) at the start of a message. The byte EOM only occurs as an S-byte at the end of a message. From the SOM byte until the following EOM byte, the following structure rules apply:

- The first two S-bytes are the Parser Code PCOD and Parser Subcode PSUB. These specify a unique parser for the data bytes. PCOD and PSUB never have values of 0x80 to 0x87, and so cannot be confused for control characters.
- Depending on PCOD and PSUB, the next byte may be an index byte INDEX. INDEX never has a value of 0x80 to 0x87, and so cannot be confused for a control character. Examples of an index are a channel number and a satellite PRN. All indexed messages with the same parser code and subcode must have the same length, format, and data structure.
- The byte HCC only occurs as an S-byte as a "stuffing" character that is used to pad certain messages to a constant length, as defined in [System class, page 60](#). It may appear before CS or any of the data bytes.
- The value of the checksum M-byte CS is such that the 8-bit sum of the M-bytes from SOM to EOM inclusive is zero. If the checksum is between 0x80 and 0x87, it is stuffed with the HCC character 0x80.
- The number of data bytes per message is limited to 128. Counting the bytes for the SOM, parser code, parser subcode, checksum, EOM, and index, the total number of M-bytes can be as many as 134. Data is not valid until the message is complete and the checksum agrees.
- HIPPO ignores any bytes between messages (from EOM to the following SOM), unless the bytes have values between 0x80 and 0x87. This feature allows ASCII messages such as NMEA or TAIP to be interspersed with HIPPO messages. TSIP messages and other binary protocols in general cannot be interspersed with HIPPO messages.

Report message structure (Module to Host)

The following table shows the message structure for a simple data packet of N M-bytes. Each message has five framing bytes: SOM; two message ID bytes (PCOD and PSUB); a checksum byte; and EOM. The data type and data structure in the message (that is, the parser) is specified by the parser code PCOD and parser subcode PSUB.

M-byte	Meaning	Value
SOM	Start of message	0x81
PCOD	Parser code	0x00 - 0x7F
PSUB	Parser subcode	0x00 - 0x7F, 0xFF
D[0]	First byte of data	0x00 - 0xFF
D[1]	Second byte of data	0x00 - 0xFF
...
D[N-1]	Last byte of data	0x00 - 0xFF
CS	Checksum	0x00 - 0xFF
EOM	End of message	0x82

Some parser code / subcodes have data indexed by channel or satellite, as shown in the following table. The index is the first byte after the parser subcode. The parser code/subcode specifies whether a message uses indexing.

M-byte	Meaning	Value
SOM	Start of message	0x81
PCOD	Parser code	0x00 - 0x7F
PSUB	Parser subcode	0x00 - 0x7F
INDEX	Data indexed by channel, and so on	0x00-0x7F, 0xFF
D[0]	First byte of data	0x00 - 0xFF
D[1]	Second byte of data	0x00 - 0xFF
...
D[N-1]	Last byte of data	0x00 - 0xFF
CS	Checksum	0x00 - 0xFF
EOM	End of message	0x82

Command message structure (Host to Module)

Command messages sent from host to module are built upon the report message structure. Except for system commands such as system reset (see [System class, page 60](#)), every command either sets or queries a reportable data structure (see [Set class, page 58](#) and [Query class, page 59](#)). To do this, the HIPPO set or query command protocol simply "wraps around" the report message protocol. The following table shows the message structure for a command to set a typical data packet:

M-byte	Meaning	Value
SOM	Start of message	0x81
CCOD	Set command code	0x01
PCOD	Parser code	0x00 - 7F
PSUB	Parser subcode	0x00 - 7F, 0xFF
D[0]	First byte of data	0x00 - FF
D[1]	Second byte of data	0x00 - FF
...
D[N-1]	Last byte of data	0x00 - FF
CS	Checksum	0x00 - FF
EOM	End of message	0x82

The following table shows the message structure for a query of indexed data:

M-byte	Meaning	Value
SOM	Start of message	0x81
CCOD	Query command code	0x02
PCOD	Parser code	0x00 - 7F
PSUB	Parser subcode	0x00 - 7F
INDEX	Index	0x00 - 7F, 0xFF
CS	Checksum	0x00 - FF
EOM	End of message	0x82

Chained messages

Chaining is not supported in the HIP module. If multiple messages are requested, they will be issued as time allows, between the high-priority automatic report messages. An acknowledgment message will appear at the end of the sequence of replies.

Post-formatting: HCC stuffing before transmission

Whenever an M-byte in the data fields or the checksum field is equal to one of the control characters (0x80 – 0x87), it generates two S-bytes — that is, the M-byte generates the S-byte pair (0x80, M-byte, and 0x7F).

Pre-parsing: HCC unstuffing after reception

Pre-parsing (assembly of the M-bytes) occurs as S-bytes are received. HIPPO pre-parsing begins with the appearance of the SOM S-byte and ends with the appearance of the EOM S-byte:

- Whenever the S-byte is SOM, a new message structure opens with room for 132 M-bytes. The first M-byte of a message is always SOM.
- Whenever the S-byte HCC appears, it does not generate a new M-byte: It generates a signal to **or** the following S-byte with 0x80 to create the next M-byte. Otherwise, the M-byte is the same as the S-byte.
- If the S-byte is EOM, the message structure is closed. The last M-byte of a message is always EOM.
- The last M-byte before the EOM is the checksum. It is computed so that the sum of all M-bytes, including the SOM, the EOM, and the checksum, is zero.

After pre-parsing is complete, the message packet is ready to be parsed into structures according to the rules in [Report class, page 60](#) and [Event log queue, page 70](#). The parser code and subcodes are the second and third M-bytes, directly after the SOM. The data will start on the fourth (non-indexed data) or fifth (indexed data) M-byte.

Possible pre-parser errors include:

- Two SOMs appear without an EOM in between.
- HCC occurs in the first two bytes (parser code and subcode).
- The byte following HCC is not equal to the 7 LSBs of a HIPPO control character.
- Control characters appear between message (after EOM but before the next SOM).
- No EOM appears in the first 134 M-bytes.

Command messages

HIPPO has three classes of command message packets:

- Set parameters: This "wraps around" the report message structure of the parameter(s) to be set.
- Query parameters: This calls out the report code and subcode (and index, if applicable) of the required reports.
- System commands

The module always acknowledges a command in one of two ways.

An explicit acknowledgment message (0x10: Acknowledge / Error response to command packets) is sent in reply to either:

- A command;
- An unsuccessful query
- A query that generates a series of report messages
- If the query successfully generates a single report message, that message is the implicit acknowledgment.

The acknowledgment contains a status indicating the completion of the operation.

Set class

The set class packets set receiver, system, and any other defined parameters within the target system. Two types of parameters can be set:

- Configuration parameters such as DOP mask (Configuration Report packets)
- Initialization parameters such as position, velocity, time, and ephemeris.

The target system returns an acknowledgment packet (0x10: Acknowledge / Error response to command packets), but does not echo data values as in TSIP.

The parser code and subcode determine the length of the command packet. The packet has the following general format (indexed data has an extra byte after parser subcode):

Byte	Name	Type	Value	Meaning
	Command code	U8	0x01	
	Parser code	U8	0x00-7F	Report Code
	Parser subcode	U8	0x00-7F	See report packet definition in Available HIPPO messages, page 52 .
0	Data value			Data corresponding to the subcode. See subcodes in the report packet definition.
...
NR-1	Data value			NR is the size of data for the specified report.

For example, to set the operating dimension to *2-D Altitude Hold*", the host issues the following command to the module:

Byte	Name	Type	Value	Meaning
	Command code	U8	0x01	
	Parser code	U8	0x24	Report packet for GNSS configuration
	Parser subcode	U8	0x01	Parameter subcode for operating dimension
0	Operating dimension	U8	3	Alt-Hold (2D)

Query class

The query class packet allows you to retrieve configuration, report, and system data with the same packet. Like the set class packet, it is indexed by the report code and subcode. This is possible because each parameter or set of parameters has a corresponding report message.

Four types of parameters can be queried:

- System parameters (for example, version numbers)
- Configuration parameters (for example, DOP mask)
- Fix parameters (for example, satellite strength, current position, velocity, time, ephemeris)
- Initialization parameters (for example, position, velocity, time, ephemeris)

The target system returns an acknowledgment packet. When a query for a single report is successful, the reply to that query is the acknowledgment. If the query fails, an explicit acknowledgment report message is sent as an acknowledgment. If the query generates a series of response messages, the last response is followed by an explicit acknowledgment report message that signals the end to the host's parser.

A query has two formats, depending on whether the information is indexed (for example, by channel or satellite).

The following table shows the query class message structure:

Byte	Name	Type	Value	Meaning
	Command code	U8	0x02	
	Parser code	U8	0x00-7F	
	Parser subcode	U8	0x00-7F	Single subcode
			0xFF	All subcodes

The following table shows the indexed query class message structure:

Byte	Name	Type	Value	Meaning
	Command code	U8	0x02	
	Parser code	U8	0x00-7F	Report Code, see Available HIPPO messages, page 52 .
	Parser subcode	U8	0x00-7F	See report packet definitions in Available HIPPO messages, page 52 .
	Index	U8	0x00-7F	Single index (for example, channel or satellite). See subcodes in the report packet definition.
			0xFF	All indices

Like the set class message, the query packet has two bytes body that contains the parser code and subcode for a configuration packet or a report packet. For example, to query the operating dimension setting in the GNSS configuration block:

Byte	Name	Type	Value	Meaning
	Command code	U8	0x02	
	Parser code	U8	0x24	Report packet for GNSS configuration
	Parser subcode	U8	0x01	Parameter subcode for operating dimension

System class

A system class packet is a set packet associated with the system operations.

Receiver Reset command messages

This command resets the receiver software.

Byte	Name	Type	Value	Meaning
	Code	U8	0x03	
	Subcode	U8	0x01	Reset
			0x02	Clear RAM, reset
			0x03	Force to Bootloader mode
			0x05	Clear ephemeris, reset
			0x07	Clear flash data and RAM, reset
			0x09	Write BBRAM to flash, reset (graceful)

Force to Bootloader Mode forces the target system to exit from the GNSS function, and into the embedded bootloader mode. The serial communication is reset to 115.2 kbps, even parity. Once in the bootloader mode, all HIPPO APIs are disabled. Refer to Flash loading documents for more detail.

Report class

Report class packets are divided into four subclasses.

- **System data** contains system information, such as system status or an event log queue entry.
- **Configuration reports** include all the system configurable parameters.
- **Data reports** have navigation information generated by the navigation platform.
- **Initialization input reports** have start-up information and GNSS system data (position, heading, almanac, and so on) and map-matching inputs for latitude, longitude, altitude, and heading.

Some report packets are indexed by channel number (tracking status, signal strength) or satellite number (almanac, ephemeris).

The parameters in the configuration and initialization reports can be set by 0x01 packet (see [Set class, page 58](#)).

The host can query all report packets using the 0x02 packet, except as noted (see [Query class, page 59](#)).

Report message code assignment

See [Available HIPPO messages, page 52](#) for all report data structures in HIPPO. This table also indicates whether the data structure can be queried (Q) or set (S). Data that can be not be queried or set is automatic output only.

Data report packets

Data report packets can be queried or output based on time interval, distance traveled, and heading change. Data validity must be checked before the data fields are translated or used.

Diagnostic report packets

The following packets are used in a post-processing routine. The contents of these packages are designed so that the routine can replicate the performance of the real-time processing. The format of these messages are not fully documented because they change as the firmware is updated.

0x70-51: Accelerometer parameter definitions

This message allows you to set or report accelerometer parameter definitions. This message is output automatically once at startup if the accelerometer is detected and is operational.

When 'setting' the data, the values are stored into non-volatile memory and the device is automatically reset for the new parameters to take effect.

Because setting the parameters results in the data being written into non-volatile storage, **this message should only be used during manufacturing/production to set the accelerometer configuration**. The user application should avoid repeatedly setting the configuration as part of normal application functionality to avoid writing to non-volatile storage without purpose, as it reduces the number of 'write cycles' that are available in the device's FLASH memory that is used for non-volatile storage.

Byte / Bit	Name	Type	Units / LSB	Range / value	Meaning
	Code	U8	0x70		
	Subcode	U8	0x51		
0	Version	U8			Version of the message format. When 'setting' data, make sure to set this field to the value returned when you first query this message.

Byte / Bit	Name	Type	Units / LSB	Range / value	Meaning
1	Operational Status / Configuration Control	U8		For query: 0, 1, 255	For automatic output or a response to a 'query' message, this field indicates the operational status: 0 = accelerometer detected/operational 1 = accelerometer not detected/present 255 = accelerometer state unknown
				For setting: bitmap	For setting the data, this field indicates which accelerometer parameters are to be changed: Bit 0 - Bytes 2-8 and Bytes 120-123 are to be changed (must be specified and valid). Bit 1 - Bytes 13-79 are to be changed (must be specified and valid). Bit 2 - Bytes 80-119 are to be changed (must be specified and valid). Byte 3 - Byte 9 is to be changed (must be specified and valid). This field can be any combination of the above bits. If any parameters are not being changed (i.e. the corresponding configuration bit is not set), the fields must still be sent as part of the message - the unchanged fields can be set to 0 when sent to the device.
2	Interface	U8		0, 1, 2	Communication interface: 0 = SPI 1 = I2C 2 = ADC
3	Type	U8		0, 1	Device type: 0 = analog 1 = digital
4	Connection	U8		0, 1, 2	Device connection: 0 = Internal (on-board) 1 = External (via connector) 2 = Connection type not applicable to product

Byte / Bit	Name	Type	Units / LSB	Range / value	Meaning
5-8	Address	U32			Device address as relevant to the device interface and type.
9	Temperature Enable	U8		0, 1, 255	Controls accelerometer temperature output in 0x70-14, if supported. 0 = output disabled 1 = output enabled 255 = not supported
10-12	<reserved>	U8[3]		0	Reserved for future use.
13-16	Bandwidth	FLT	Hz		System bandwidth.
17-20	X-axis Measurement Range	FLT	g		X-axis maximum measurement value.
21-24	X-axis Sensitivity	FLT	mg/LSB or mg/mV		X-axis sensitivity. For digital accelerometers, the units are mg/LSB; for analog - mg/mV. (LSB: least significant bit, digit.)
25	X-axis Data Output Resolution	U8	bits		Effective number of bits used for X-axis data conversion. For digital accelerometers, this value is provided in the datasheet; for analog, it depends on the host processor's ADC.
26-29	X-axis Noise Density	FLT	mg/sqrt(Hz)		X-axis noise density
30-33	X-axis Colored Noise Density	FLT	mg/sqrt(Hz)		X-axis colored noise density
34-37	X-axis Zero-g Offset Accuracy / Level	FLT	mg or mV		X-axis zero-g level offset accuracy. For digital accelerometers, the units are mg; for analog - mV.
38-41	Y-axis Measurement Range	FLT	g		Y-axis maximum measurement value.
42-45	Y-axis Sensitivity	FLT	mg/LSB or mg/mV		Y-axis sensitivity.
46	Y-axis Data Output Resolution	U8	bits		Effective number of bits used for Y-axis data conversion.
47-50	Y-axis Noise Density	FLT	mg/sqrt(Hz)		Y-axis noise density.
51-54	Y-axis Colored Noise Density	FLT	mg/sqrt(Hz)		Y-axis colored noise density.
55-58	Y-axis Zero-g Offset Accuracy / Level	FLT	mg or mV		Y-axis zero-g level offset accuracy.

Byte / Bit	Name	Type	Units / LSB	Range / value	Meaning
59-62	Z-axis Measurement Range	FLT	g		Z-axis maximum measurement value.
63-66	Z-axis Sensitivity	FLT	mg/LSB or mg/mV		Z-axis sensitivity.
67	Z-axis Data Output Resolution	U8	bits		Effective number of bits used for Z-axis data conversion.
68-71	Z-axis Noise Density	FLT	mg/sqrt(Hz)		Z-axis noise density.
72-75	Z-axis Colored Noise Density	FLT	mg/sqrt(Hz)		Z-axis colored noise density.
76-79	Z-axis Zero-g Offset Accuracy / Level	FLT	mg or mV		Z-axis zero-g level offset accuracy.
80-83	Lever Arm Length	FLT	m		Distance from accelerometer to the vehicle's rear axle.
84-87	X-axis value of the forward direction unit vector	FLT			X value of the unit vector in the vehicle's forward direction expressed in the accelerometer XYZ coordinates.
88-90	Y-axis value of the forward direction unit vector	FLT			Y value of the unit vector in the vehicle's forward direction expressed in the accelerometer XYZ coordinates.
92-95	Z-axis value of the forward direction unit vector	FLT			Z value of the unit vector in the vehicle's forward direction expressed in the accelerometer XYZ coordinates.
96-99	X-axis value of the left direction unit vector	FLT			X value of the unit vector in the vehicle's left direction expressed in the accelerometer XYZ coordinates.
100-103	Y-axis value of the left direction unit vector	FLT			Y value of the unit vector in the vehicle's left direction expressed in the accelerometer XYZ coordinates.
104-107	Z-axis value of the left direction unit vector	FLT			Z value of the unit vector in the vehicle's left direction expressed in the accelerometer XYZ coordinates.
108-111	X-axis value of the up direction unit vector	FLT			X value of the unit vector in the vehicle's up direction expressed in the accelerometer XYZ coordinates.

Byte / Bit	Name	Type	Units / LSB	Range / value	Meaning
112-115	Y-axis value of the up direction unit vector	FLT			Y value of the unit vector in the vehicle's up direction expressed in the accelerometer XYZ coordinates.
116-119	Z-axis value of the up direction unit vector	FLT			Z value of the unit vector in the vehicle's up direction expressed in the accelerometer XYZ coordinates.
120-123	Device ID	U32			Device identification code.

0x70-60: Mounting Angle Calibration

This message allows setting or reporting the mounting angle calibration data. This message is automatically output once at startup. When 'setting' the data, the values are stored into non-volatile memory. There are two different message formats for 'setting' and 'querying/reporting' the data.

0x70-60: Query/report' format for the Mounting Angle Calibration

Byte / Bit	Name	Type	Units / LSB	Range / value	Meaning
	Code	U8	0x70		
	Subcode	U8	0x60		
0	Version	U8		0x02	Version of the message format. When 'setting' data, make sure to set this field to the value reflected in this reference table.
1	Status	U8			Mounting angle calibration status: 0 = angle unknown 1 = angle set from user input 2 = angle set at manufacturing
2-5	X-axis value of the forward direction unit vector	FLT		-1...1	X value of the unit vector in the vehicle's forward direction expressed in the gyro XYZ coordinates.
6-9	Y-axis value of the forward direction unit vector	FLT		-1...1	Y value of the unit vector in the vehicle's forward direction expressed in the gyro XYZ coordinates.
10-13	Z-axis value of the forward direction unit vector	FLT		-1...1	Z value of the unit vector in the vehicle's forward direction expressed in the gyro XYZ coordinates.

Byte / Bit	Name	Type	Units / LSB	Range / value	Meaning
14-17	X-axis value of the left direction unit vector	FLT		-1...1	X value of the unit vector in the vehicle's left direction expressed in the gyro XYZ coordinates.
18-21	Y-axis value of the left direction unit vector	FLT		-1...1	Y value of the unit vector in the vehicle's left direction expressed in the gyro XYZ coordinates.
22-25	Z-axis value of the left direction unit vector	FLT		-1...1	Z value of the unit vector in the vehicle's left direction expressed in the gyro XYZ coordinates.
26-29	X-axis value of the up direction unit vector	FLT		-1...1	X value of the unit vector in the vehicle's up direction expressed in the gyro XYZ coordinates.
30-33	Y-axis value of the up direction unit vector	FLT		-1...1	Y value of the unit vector in the vehicle's up direction expressed in the gyro XYZ coordinates.
34-37	Z-axis value of the up direction unit vector	FLT		-1...1	Z value of the unit vector in the vehicle's up direction expressed in the gyro XYZ coordinates.
38-41	Calibration time of week	U32	sec		GPS time of week of the last self-calibration time.
42-43	Calibration week number	S16	weeks		GPS week number of the last self-calibration time.
44-51	Latitude of calibration	DBL	deg		Latitude of the location of the last self-calibration.
52-59	Longitude of calibration	DBL	deg		Longitude of the location of the last self-calibration.
60-67	Altitude of calibration	DBL	m		Altitude of the location of the last self-calibration.
68	Matching profile index	U8			Index in the profile array of the profile matched during the last self-calibration. This field is applicable only if Status = 3. The profile array is set or reported using 0x70-61.
69	Self-calibration Progress	U8	%	0-100	Self-calibration progress, expressed as percentage.

0x70-60: 'Set' format for the Mounting Angle Calibration

Byte / Bit	Name	Type	Units / LSB	Range / value	Meaning
	Code	U8	0x70		
	Subcode	U8	0x60		

Byte / Bit	Name	Type	Units / LSB	Range / value	Meaning
0	Version	U8		0x02	Version of the message format. When 'setting' data, make sure to set this field to the value reflected in this reference table.
1	Command	U8			Mounting angle calibration command: 0 = set the mounting angle unit vectors as specified in this packet 3 = use the mounting angle programmed at manufacturing. All other fields in this packet will be ignored. If manufacturing data is not available, an error is returned.
2-5	X-axis value of the forward direction unit vector	FLT		-1...1	X value of the unit vector in the vehicle's forward direction expressed in the gyro XYZ coordinates.
6-9	Y-axis value of the forward direction unit vector	FLT		-1...1	Y value of the unit vector in the vehicle's forward direction expressed in the gyro XYZ coordinates.
10-13	Z-axis value of the forward direction unit vector	FLT		-1...1	Z value of the unit vector in the vehicle's forward direction expressed in the gyro XYZ coordinates.
14-17	X-axis value of the left direction unit vector	FLT		-1...1	X value of the unit vector in the vehicle's left direction expressed in the gyro XYZ coordinates.
18-21	Y-axis value of the left direction unit vector	FLT		-1...1	Y value of the unit vector in the vehicle's left direction expressed in the gyro XYZ coordinates.
22-25	Z-axis value of the left direction unit vector	FLT		-1...1	Z value of the unit vector in the vehicle's left direction expressed in the gyro XYZ coordinates.
26-29	X-axis value of the up direction unit vector	FLT		-1...1	X value of the unit vector in the vehicle's up direction expressed in the gyro XYZ coordinates.
30-33	Y-axis value of the up direction unit vector	FLT		-1...1	Y value of the unit vector in the vehicle's up direction expressed in the gyro XYZ coordinates.
34-37	Z-axis value of the up direction unit vector	FLT		-1...1	Z value of the unit vector in the vehicle's up direction expressed in the gyro XYZ coordinates.

0x70-61: Mounting Angle Profiles

This message allows setting or reporting of the mounting angle profiles. The profiles are used to match the self-calibrated mounting angle to a more accurate, pre-set angle. This message is output automatically once at startup. When 'setting' the data, the values are stored into non-volatile memory.

Note – When 'setting' the profiles, the mounting angle is automatically re-calibrated and matched to one of the specified profiles, if any, even if the angle was previously set or calibrated.

Byte / Bit	Name	Type	Units / LSB	Range / value	Meaning
	Code	U8	0x70		
	Subcode	U8	0x61		
0	Version	U8		0x01	Version of the message format. When 'setting' data, make sure to set this field to the value reflected in this reference table.
1	Number of profiles (N)	U8		0...10	Number of calibration profiles that follow. If 0, the mounting angle is re-calibrated with no profile matching.
2-5	Profile 1: X-axis value of the up direction unit vector	FLT		-1...1	1st profile's X value of the unit vector in the vehicle's up direction expressed in the gyro XYZ coordinates.
6-9	Profile 1: Y-axis value of the up direction unit vector	FLT		-1...1	1st profile's Y value of the unit vector in the vehicle's up direction expressed in the gyro XYZ coordinates.
10-13	Profile 1: Z-axis value of the up direction unit vector	FLT		-1...1	1st profile's Z value of the unit vector in the vehicle's up direction expressed in the gyro XYZ coordinates.
...
2+(N-1)*12 - 5+(N-1)*12	Profile N: X-axis value of the up direction unit vector	FLT		-1...1	Nth profile's X value of the unit vector in the vehicle's up direction expressed in the gyro XYZ coordinates.
6+(N-1)*12 - 9+(N-1)*12	Profile N: Y-axis value of the up direction unit vector	FLT		-1...1	Nth profile's Y value of the unit vector in the vehicle's up direction expressed in the gyro XYZ coordinates.
10+(N-1)*12 - 13+(N-1)*12	Profile N: Z-axis value of the up direction unit vector	FLT		-1...1	Nth profile's Z value of the unit vector in the vehicle's up direction expressed in the gyro XYZ coordinates.

0x70-7F: Toggle Diagnostics Output

This message controls output of the 0x70 messages. Each U32 field is a 32-bit mask controlling a set of 32 messages as specified in the *Meaning* column. The LSB of each U32 is for the lower-numbered message in a range (for example, Bit 0 of Set#2 is for 0x70-20). If a given bit is 1, the corresponding message is enabled to be output; if 0, disabled.

Byte	Name	Type	Units / LSB	Range / value	Meaning
	Code	U8	0x70		
	Subcode	U8	0x7F		
0 - 3	Flag bits set #1	U32	bitmap	1 = on	Flag bits for messages 0x70-00 ... 0x70-1F
				0 = off	
4 - 7	Flag bits set #2	U32	bitmap	1 = on	Flag bits for messages 0x70-20 ... 0x70-3F
				0 = off	
8 - 11	Flag bits set #3	U32	bitmap	1 = on	Flag bits for messages 0x70-40 ... 0x70-5F
				0 = off	
12-15	Flag bits set #4	U32	bitmap	1 = on	Flag bits for messages 0x70-60 ... 0x70-7F
				0 = off	

Event log queue

Theory of Operation

There are two types of events, hard and soft and each type has its separate log: The soft event log resides in RAM and the fatal error log resides in flash. Each event has an event ID (two-byte unsigned value, see [Port configuration, page 33](#)), a time tag indicating the time when the event occurred, and a status word if applicable.

Fatal errors

Fatal errors indicate abnormal operation of the module. In general these errors (such as illegal address) are not recoverable. Under these conditions, the receiver writes to the log first, and then sends an event packet to notify user before it restarts (warm or cold reset). The fatal errors are divided based on the source of error:

- Interrupt system errors have a high byte of 0x10. The low byte is the vector number at fault.
- Hardware-related system error, for example, RAM, ROM, or gyro, has a high byte of 0x12 or 0x13.
- RTOS events (errors related to the Operating System related function calls) have a high byte of 0x20.
- Navigation library events and run-time positioning diagnostics have a high byte of 0x40.

Error/Event		Descriptions	Action
LOG_ILL_TRAP	0x10xx	Illegal hardware interrupts (xx = vector number)	Hard reset
LOG_ERR_RAM_FAILED	0x1200	RAM failed on self-test	Monitor mode
LOG_ERR_ROM_FAILED	0x1201	ROM failed on checksum test	Monitor mode
LOG_GET_SEMAPHORE_ERR	0x2001	Failure on acquiring a semaphore	Reset
LOG_RELEASE_SEMAPHORE_ERR	0x2002	Failure on releasing a semaphore	Reset
LOG_SEND_MESSAGE_ERR	0x2003	Failure on sending a message	Reset
LOG_RECEIVE_MESSAGE_ERR	0x2004	Failure on receiving a message	Reset
LOG_DELETE_MESSAGEQ_ERR	0x2005	Failure on deleting a message queue	Reset
LOG_DELETE_TASK_ERR	0x2006	Failure to remove task from system	Reset
LOG_SUSPEND_TASK_ERR	0x2007	Failure on suspending a task	Reset
LOG_RESUME_TASK_ERR	0x2008	Failure on resuming a task	Reset
LOG_CREATE_SEMAPHORE_ERR	0x2009	Failure on creating a semaphore	Reset
LOG_CONNECTION_ERR	0x200A	Failure to connect to lo-DSP cell	
LOG_CREATE_TASK_ERR	0x200B	Failure to creating a task	Reset
LOG_ALLOCATE_BUF_ERR	0x200C	Failure on memory allocation	Reset
LOG_MESSAGEQ_FULL	0x2120	A given message queue is full	Reset

Error/Event		Descriptions	Action
LOG_SIO_OPEN_ERR	0x2121	Failure to open serial port	Monitor mode
LOG_NAV_HARD_COCOM	0x4001	COCOM event, no recovery	Hard reset
LOG_NAV_HARD_ERR	0x4003	Other error in navigation library	Hard reset

The fatal error log is located in the Flash memory space. There are 31 reportable entries with 32 bytes per entry. The host cannot erase this log. A write-after-erase algorithm ensures the integrity of the log.

The following table shows the format of the fatal error log entry:

Field	Type	Descriptions
Msec	U32	Time tag in GPS milliseconds (0xffffffff if not available)
Week	U16	Time tag in GPS week number (0xffff if not available)
Code	U16	Event/error code. Hard reset means "Clear RAM and Reset SW". The column "Ver" indicates which ROM versions have this fatal error code feature.
Status	U16	Status code associated with the event. 0 if it does not apply.
Info block	22 bytes	See tables, below.

The last field holds information associated with type of error. It can be a stack frame, a memory dump up to 22 bytes, or the program count for the address of error. The following tables describe the format for each fatal error types.

Block format for the status code 10xx:

Field	Type	Descriptions
Vector	U8	Illegal vector number
PC	U32	Program counter at fault
SP	U32	Supervisor stack address

Block format for the status code 12xx:

Field	Type	Descriptions
Soft value	U32	Soft checksum or memory content.
Actual value	U32	Data read from the target.
Address	U32	Status code 1201 only.

Block format for the status code 2xxx:

Field	Type	Descriptions
Src task	U8	Caller task ID
Dest task	U8	Receive task ID - 0 if not applicable.
Resource ID	U8	System resource such as semaphore, message queue.

Soft events

Soft events, which include soft errors, periodic events, and user requested events, occur frequently. Only selected events will be logged into BBRAM. None of these events triggers a software reset. If the host desires to be notified of specific events with a HIPPO output message, it can specify the events to report with the event mask function, see [Failure to connect to GNSS DSP, page 76](#).

Soft events have a 7-bit identity code and a two-bit condition status code.

The soft event identity code is between 1 and 127, as defined in [Port configuration, page 33](#). The last column indicates whether the event is a persistent condition such as a shorted antenna (C) or a single event like a RTC fault (S).

Some of these soft events are "informational", and result from user action. Those soft events that are generated internally are explained in more detail starting in [Invalid BBRAM detected on startup, page 73](#).

The condition code has four states. For a single event, the condition status code is zero. For a soft event condition, the condition code is defined in the following table:

Numeric value	Descriptions
0x00	Status unknown (backwards compatible to old software) or single event
0x10	Newly detected condition
0x20	Condition previously detected, still present
0x30	Condition newly cleared

As an example, when an antenna short condition is first detected, a soft event with identity and condition codes (0x71, 0x10) is generated. Every second, when the antenna fault detection is repeated, the soft event (0x71, 0x20) is generated. When the condition is cleared and no fault is found, the soft event (0x71, 0x30) is generated.

The soft event log resides at the beginning of the RAM area in a circular buffer with 127 entries. The log records all single-event soft events and all changes in soft event conditions, but does not record soft events with status code 0x20 (condition previously detected, still present). The log persists as long as there is a battery-backup power. The user can erase the log via a HIPPO command or by the startup RAM test (cold start only). The host can retrieve logs at any time via HIPPO query. The following table shows the format of the log entry for soft events:

Field	Type	Descriptions
Msec	U32	Time tag in GNSS milliseconds.
Week	U16	Time tag in GNSS week number.
Identity	U8	Soft event identity code, see Invalid BBRAM detected on startup, page 73 .
Condition	U8	Soft event condition code Position recovery, solution snapped to GNSS, page 73 .
Reserved	U16	

Invalid BBRAM detected on startup

Condition cause	Hardware failure.
Effect before action	If not cleared, very long time to first fix or worse.
Soft event detected	BBRAM checksum mismatch at power-up.
Action	Clear BBRAM.

Position recovery, solution snapped to GNSS

Condition cause	Incorrect position at start-up, or substantial drift of DR-GNSS position estimate.
Effect before action	Large position offset between GNSS and DR outputs for a number of seconds.
Soft event detected	Compute average of "window" of recent unfiltered GNSS positions, propagated to current time using GNSS velocities. Soft event occurs if this window average passes a series of criteria (see DR-GNSS KF algorithm document 45172-XX-SP) and the offset relative to the DR position is large enough.
Action	The DR position is snapped to the window average.

Heading recovery, solution snapped to GNSS

Condition cause	Incorrect heading at start-up, or substantial drift of DR-GNSS heading estimate.
Effect before action	Large heading offset between GNSS and DR outputs for a number of seconds.
Soft event detected	Compute average of "window" of recent raw GNSS headings, propagated to current time gyro measurements. Soft event occurs if this window average passes a series of criteria (see DR-GNSS KF algorithm document 45172-XX-SP) and the offset relative to the DR heading is large enough.
Action	The DR heading is snapped to the window average.

DPP recovery, solution snapped to GNSS

Condition cause	Incorrect DPP at start-up, or substantial drift of DR-GNSS DPP estimate.
Effect before action	Large speed offset between GNSS and DR outputs for a number of seconds.

Soft event detected	Compute average of "window" of recent DPP estimates, derived directly from the raw GNSS speed and number of pulses. Soft event occurs if this window average passes a series of criteria (see DR-GNSS KF algorithm document 45172-XX-SP) and the offset relative to the DR DPP is large enough.
Action	The DPP estimate is snapped to the window average.

GNSS receiver fixes not reasonable; try to recover

Condition cause	Pseudorange error or ephemeris error.
Effect before action	GNSS positions incorrect.
Soft event detected	Fix altitude is above 18000 m or below -1000 m and fix speed is above 515 m/s.
Soft event cleared	Cleared at reset.
Action (ROM15)	Erase BBRAM and RTC, re-start unit.

Gyro readings do not stay within specification

Condition cause	Hardware failure.
Effect before action	Position goes in circles.
Soft event detected	Average gyro reading over ten seconds at standstill is not between 2.0 V and 3.0 V.
Soft event cleared	Cleared at reset.
Action	Gyro labeled "bad". DR suspended. Speed measurement continues and speed signal input continues to be calibrated.

No speed signal input data when GNSS is detecting movement

Condition cause	Speed signal input is disconnected or malfunctioning.
Effect before action	Position solution will be not change when moving.
Soft event detected	GNSS speed > 8.0 m/s and no speed signal input pulses reported (except heartbeats) for 15 GNSS fixes.
Soft event cleared	Speed signal input pulse is reported, or unit is reset.
Action	Speed signal input labeled as "absent". DR is suspended. Heading measurement continues and gyro continues to be calibrated.

Excessive speed signal input data is received for a long period of time

Condition cause	Wheels spinning, other speed signal input malfunction.
Effect before action	Position fixes move at higher speed than actual position.
Soft event detected	Not implemented. Function partly done by DPP recovery.

Reverse signal opposite to direction determined by GNSS

Condition cause	Disconnected reverse switch.
Effect before action	Reverse driving is mistaken for forward driving, resulting in incorrect position.
Soft event detected	Driving in reverse at raw GNSS speed > 14 m/s.
Soft event cleared	Driving forward at raw GNSS speed > 14 m/s.
Action	Direction switch sense changed.

Large jump at power-up

Condition cause	Position in BBRAM incorrect (for example, travel by ferry).
Effect before action	Positions are offset by many kilometers after power-up.
Soft event detected	Offset between first three GNSS points and DR position > 2000 m.
Action	Reset position to average GNSS position.

Oscillator values are not within specification

Condition cause	Excessive temperature response or aging of crystal.
Effect before action	Extended time-to-first fix.
Soft event detected	Not implemented.

Antenna open detected

Condition cause	Hardware failure.
Effect before action	No GNSS positions.
Soft event detected	Hardware signal queried at one Hz.
Soft event cleared	Hardware signal queried at one Hz.
Action	DR functions without GNSS positions.

Antenna short detected

Condition cause	Hardware failure.
Effect before action	No GNSS positions.
Soft event detected	Hardware signal queried at one Hz.
Soft event cleared	Hardware signal queried at one Hz.
Action	DR functions without GNSS positions.

Failure to connect to GNSS DSP

Condition cause	Hardware failure.
Effect before action	No GNSS positions.
Soft event detected	No response from DSP within 5 seconds.
Action	DR functions without GNSS positions.

RTC disagreed with GNSS time

Condition cause	Low battery voltage while powered down.
Effect before action	Long time to first fix.
Soft event detected	Not implemented.

Gyro failure

Condition cause	Hardware failure.
Effect before action	Position goes in circles.
Soft event detected	Tested with ADC at startup. Also tested at standstill; average gyro values (one-second averages) are collected over ten seconds at standstill. If average is not between 0.75 V and 4.25 V, declare detection.
Soft event cleared	Cleared at reset.
Action	Gyro labeled "bad". DR suspended. Speed measurement continues and speed signal input continues to be calibrated.

ADC failure

Condition cause	Hardware failure.
Effect before action	Position goes in circles.
Soft event detected	At power-up.
Action	Gyro labeled "bad". DR suspended. Speed measurement continues and speed signal input continues to be calibrated.

Gyro shorted to 3.3 V

Condition cause	Hardware failure.
Effect before action	Position goes in circles.
Soft event detected	Average and range of gyro values (one-second averages) are collected over ten seconds at standstill. If average is between 3.05 V and 3.55 V, and range is less than 6 mV, declare detection.

Soft event cleared	Cleared at reset.
Action	Gyro labeled "bad". DR suspended. Speed measurement continues and speed signal input continues to be calibrated.

NMEA 0183 Protocol

In this appendix:

- [Introduction](#)
- [NMEA protocol overview](#)
- [NMEA 0183 communication interface](#)
- [NMEA 0183 message structure](#)
- [Field definitions](#)
- [Message options](#)
- [Standard NMEA messages](#)
- [Proprietary NMEA messages](#)

This appendix provides a brief overview of the NMEA 0183 protocol, and describes both the standard and optional messages offered by the Bison firmware.

Introduction

The Bison firmware supports an industry-standard NMEA 0183 communication protocol. The protocol supports two categories of messages—standard and proprietary messages. The standard messages adhere to a universal definition specified by the National Marine Electronics Association. The proprietary messages use Trimble Component Technology's own definitions.

The following table lists NMEA messages implemented and available in the Bison firmware. It also indicates whether a particular message can be queried (Q) or set (S). Refer to the NMEA Protocol Specification for detailed information

Standard NMEA messages

Message	Description	Q	S
GGA	GNSS fix data	Q	
GSA	DOP and active satellites	Q	
GSV	GNSS satellites in view	Q	
RMC ¹	Recommended minimum specific GNSS data	Q	
VTG ¹	Course over ground and ground speed	Q	
ZDA ¹	Time and date	Q	

¹Some elements of these NMEA messages are not supported in the current Bison firmware.

Standard NMEA messages are output automatically based on the automatic message mask and output interval which can be configured with the NM message. The default behavior is for automatic, once per second output of the following standard messages: GGA, RMC, VTG, GSV, and GSA.

Proprietary NMEA messages

Message	Description	Q	S
BA	Antenna status	Q	
EM	Set device into Monitor mode (for firmware update)		S
NM	NMEA automatic message output control	Q	S
PT	Serial port and output protocol configuration	Q	S
RT	Reset device		S
TP	Temperature data	Q	
VR	Version information	Q	

NMEA protocol overview

NMEA 0183 is a simple, yet comprehensive ASCII protocol which defines both the communication interface and the data format. The NMEA 0183 protocol was originally established to allow marine navigation equipment to share information. Since it is a well established industry standard, NMEA 0183 has also gained popularity for use in applications other than marine electronics.

For those applications requiring output only from the GNSS receiver, NMEA 0183 is a popular choice since, in many cases, an NMEA 0183 software application code already exists.

NMEA 0183 communication interface

NMEA 0183 allows a single source (talker) to transmit serial data over a single twisted wire pair to one or more receivers (listeners). The table below lists the standard characteristics of the NMEA 0183 data transmissions.

Signal	NMEA standard
Baud rate	4800
Data bits	8
Parity	None (disabled)
Stop bits	1

NMEA 0183 message structure

The NMEA 0183 protocol covers a broad array of navigation data. This broad array of information is separated into discrete messages which convey a specific set of information. The entire protocol encompasses over 50 messages, but only a sub-set of these messages apply to a GNSS receiver like the Condor module. The NMEA message structure is described below.

$$\$IDMSG, D1, D2, D3, D4, \dots, Dn * CS [CR] [LF]$$

Where:

\$	Signifies the start of a message
ID	The talker identification is a two letter mnemonic which describes the source of the navigation information. The GP identification signifies a GNSS source.
MSG	The message identification is a three letter mnemonic which describes the message content and the number and order of the data fields.
,	Commas serve as delimiters for the data fields.
Dn	Each message contains multiple data fields (Dn) which are delimited by commas.
*	The asterisk serves as a checksum delimiter.
CS	The checksum field contains two ASCII characters which indicate the hexadecimal value of the checksum.
[CR] [LF]	The carriage return [CR] and line feed [LF] combination terminate the message.

NMEA 0183 messages vary in length, but each message is limited to 79 characters or less. This length limitation excludes the "\$" and the [CR][LF]. The data field block, including delimiters, is limited to 74 characters or less.

Field definitions

Many of the NMEA data fields are of variable length, and the user should always use the comma delineators to parse the NMEA message data field. The following table specifies the definitions of all field types in the NMEA messages supported by Trimble:

Type	Symbol	Definition
Status	A	Single character field: A=Yes, data valid, warning flag clear V=No, data invalid, warning flag set
Special Format Fields		
Latitude	lll.l	Fixed/variable length field: Degreesminutes.decimal-2 fixed digits of degrees, 2 fixed digits of minutes and a variable number of digits for decimal-fraction of minutes. Leading zeros always included for degrees and minutes to maintain fixed length. The decimal point and associated decimal-fraction are optional if full resolution is not required.
Longitude	yyyyy.yyy	Fixed/Variable length field: Degreesminutes.decimal-3 fixed digits of degrees, 2 fixed digits of minutes and a variable number of digits for decimal-fraction of minutes. Leading zeros always included for degrees and minutes to maintain fixed length. The decimal point and associated decimal-fraction are optional if full resolution is not required.
Time	hhmmss.ss	Fixed/Variable length field: hoursminutessseconds.decimal-2 fixed digits of minutes, 2 fixed digits of seconds and a variable number of digits for decimal-fraction of seconds. Leading zeros always included for hours, minutes, and seconds to maintain fixed length. The decimal point and associated decimal-fraction are optional if full resolution is not required.
Defined		Some fields are specified to contain pre-defined constants, most often alpha characters. Such a field is indicated in this standard by the presence of one or more valid characters. Excluded from the list of allowable characters are the following that are used to indicated field types within this standard: "A", "a", "c", "hh", "hhmmss.ss", "lll.l", "x", "yyyyy.yy"
Numeric Value Fields		
Variable	x.x	Variable length integer or floating numeric field. Optional leading and trailing zeros. The decimal point and associated decimal-fraction are optional if full resolution is not required (example: 73.10=73.1=073.1=73).
Fixed HEX	hh	Fixed length HEX numbers only, MSB on the left
Information Fields		
Fixed Alpha	aa	Fixed length field of upper-case or lower-case alpha characters.
Fixed Number	xx	Fixed length field of numeric characters

Note –

- Spaces should only be used in variable text fields.
- Units of measure fields are appropriate characters from the Symbol column unless a specified unit of measure is indicated.
- Fixed length field definitions show the actual number of characters. For example, a field defined to have a fixed length of 5 HEX characters is represented as hhhhh between delimiters in a sentence definition.

Message options

Any given product can output any or all of the messages listed in the product specification or design document. Typically NMEA messages are output at a 1 second interval with the "GP" talker ID and checksums. These messages are output at all times during operation, with or without a fix. If a different set of messages other than the factory default has been selected (using a relevant configuration command), and this setting has been stored in flash memory (if supported), the default messages are permanently replaced until the receiver is returned to the factory default state.

The user can configure a custom mix of the messages. All products typically provide a message output configuration command to select which messages to output and at what interval.

Standard NMEA messages

In the following message format descriptions:

- Each message ends with *hh<CR><LF> where:
 - * - ASCII asterisk character
 - hh - computed message checksum (2-digit hex value)
 - <CR> - carriage-return character (hex value 0x0D)
 - <LF> - line-feed character (hex value 0x0A)
- Bold items are literal, and must be present in the message.
- If an item is unavailable, it will be blank, but the comma delimiter must be present.
- An "x" is an optional character which may or may not be present to add precision or to indicate negativity.

GGA: Global Positioning System Fix Data

Time, position and fix related data for the GNSS receiver.

This message is output automatically if selected in the NMEA message output mask. On some products, it can also be queried using the command: `$GPGPQ, GGA*hh<CR><LF>`

```
$GPGGA, hhmmss.s, llll.lllx, d, yyyyy.yyyx, d, q, s, xh.hx,
xaaaa, M, xggg, M, xxx, xxxx*hh<CR><LF>
```

Field	Description
hhmmss.s	Hours, minutes, seconds, sub-seconds of position in UTC
llll.lllx	Latitude
d	N (North) or S (South)
yyyyy.yyyx	Longitude
d	E (East) or W (West)
q	GNSS quality Indicator: 0 = No GNSS, 1 = GNSS, 2 = DGNSS, 6 = DR
s	Number of satellites in use
xh.hx	Horizontal Dilution of Precision (HDOP)
xaaaa	Antenna altitude in meters, M = Meters
xggg	Geoidal separation <i>Note – Geoidal separation is the difference between the WGS-84 earth ellipsoid and mean-sea-level.</i>
xxx	Age of differential GNSS data
xxxx	Differential Reference Station ID
hh	Checksum

GSA: DOP and Active Satellites

GNSS receiver's operating mode, satellites used in navigation solution reported by the `$GPGGA` message, and DOP values.

This message is output automatically if selected in the NMEA message output mask. On some products, it can also be queried using the command `$GPGPQ, GSA*hh<CR><LF>`

```
$GPGSA, m, s, n1, n2, n3, n4, n5, n6, n7, n8, n9, n10, n11, n12, xp.px, xh.h.x, xv.vx*hh<CR><LF>
```

Field number	Description
m	Mode: M = Manual, A = Automatic. In manual mode, the receiver is forced to operate in either 2D or 3D mode. In automatic mode, the receiver is allowed to switch between 2D and 3D modes subject to the PDOP and satellite masks.
s	Status: 1 = fix not available, 2 = 2D, 3 = 3D
n1 ... n12	PRN numbers of the satellites used in the position solution. When less than 12 satellites are used, the unused fields are null.
xp.px	Position dilution of precision (PDOP)

Field number	Description
xh.hx	Horizontal dilution of precision (HDOP)
xv.vx	Vertical dilution of precision (VDOP)
hh	Checksum

GSV: GNSS Satellites in View

Number of satellites in view, PRN numbers, elevation, azimuth and SNR value. Four satellites maximum per transmission, additional satellite data sent in second or third message. Total number of messages being transmitted and the number of the message being transmitted is indicated in the first two fields.

This message is output automatically if selected in the NMEA message output mask. On some products, it can also be queried using the command `$GPGPQ,GSV*hh<CR><LF>`

```
$GPGSV,t,m,ts,n1,e1,aa1,s1,n2,e2,aa2,s2,n3,e3,aa3,s3,n4,e4,aa4,s4*hh
<CR><LF>
```

Field number	Description
t	Total number of GSV messages
m	Message number
ts	Total number of satellites in view
n1 ... n4	Satellite PRN number
e1 ... e4	Elevation in degrees (90° Maximum)
aa1 ... aa4	Azimuth in degrees true (000 to 359)
s1 ... s4	SNR (00 - 99 dBHZ)
hh	Checksum

RMC: Recommended Minimum Specific GNSS/Transit Data

Time, date, position, course, and speed data provided by a GNSS receiver.

This message is output automatically if selected in the NMEA message output mask. On some products, it can also be queried using the command `$GPGPQ,RMC*hh<CR><LF>`

```
$GPRMC,hhmmss.s,s,llll.lllx,d,yyyyy.yyyx,d,xs.sx,xc.cx,ddmmyy,xm.vx,
d,a*hh<CR><LF>
```

Field number	Description
hhmmss.s	UTC of Position Fix (when UTC offset has been decoded by the receiver).
s	Status: A - Valid, V - Data not valid
llll.lllx	Latitude
d	N (North) or S (South)
yyyyy.yyyx	Longitude

Field number	Description
d	E (East) or W (West)
xs.sx	Speed over the ground (SOG) in knots
xc.cx	Course over ground in degrees true
ddmmyy	Date: day, month, year
xm.vx	Magnetic variation in degrees. Not supported.
d	E = East / W= West. Not supported.
a	Mode: A - Autonomous, E - Estimated (DR)
hh	Checksum (mandatory for RMC)

VTG: Course over Ground and Ground Speed

The actual course and speed relative to ground.

This message is output automatically if selected in the NMEA message output mask. On some products, it can also be queried using the command `$GPGPQ,VTG*hh<CR><LF>`

`$GPVTG,xc.cx,T,xc.cx,M,xs.sx,N,xs.sx,K,a*hh<CR><LF>`

Field	Description
xc.cx	Course over ground in degrees true.
xc.cx	Course over ground in degrees magnetic. Not supported.
xs.sx	Speed over ground in knots.
xs.sx	Speed over ground in km / hr
a	Mode: A - Autonomous, E - Estimated (DR)
hh	Checksum

ZDA: Time and Date

UTC, day, month, year, and local time zone.

This message is output automatically if selected in the NMEA message output mask. On some products, it can also be queried using the command `$GPGPQ,ZDA*hh<CR><LF>`

`$GPZDA,hhmmss.s,dd,mm,yyyy,zh,zm*cs`

Field	Description
hhmmss.s	Hours, minutes, seconds, sub-seconds of position in UTC
dd	Day (01 to 31)
mm	Month (01 to 12)
yyyy	Year
zh	Local zone hour, offset from UTC to obtain local time. Not supported.
zm	Local zone minute. Not supported.

Proprietary NMEA messages

AN: Antenna Configuration

This message configures the antenna.

Query format: \$PTNLQAN*hh<CR><LF>

Set format: \$PTNLaAN, x.x, x.x, x.x, x.x, x.x*hh<CR><LF>

Field	Description
a	Mode (S = set; R = response)
x.x	Internal antenna open threshold. This is the value of the current, in ADC counts, below which the antenna line is considered open. NULL if not applicable.
x.x	Internal antenna short threshold. This is the value of the current, in ADC counts, above which the antenna line is considered shorted. NULL if not applicable.
x.x	Internal antenna power delay (microseconds). This is a delay after the internal antenna power is turned on after a short condition is removed. NULL if not applicable.
x.x	External antenna short pulse width (microseconds). This is the width of the pulse generated on the external antenna short pin for activating the external open/short detection circuitry.
x.x	External antenna short pulse delay (microseconds). This is the delay after the pulse is generated on the short pin before the pin is used for reading the antenna short status.

Response to set format: \$PTNLRAN, a*hh<CR><LF>

Field	Description
a	Status (A - success; V - failure)

BA: Antenna Status

This message queries the antenna status. Set is not supported. This message is output automatically if selected in the NMEA message output mask.

Query format: \$PTNLQBA*hh<CR><LF>

Response to query format: \$PTNLRBA, a, a*hh<CR><LF>

Field	Description
a	Status
	0 = status unavailable,
	1 = status available
a	Antenna feedline fault :
	0 = normal

Field	Description
	1 = open
	2 = short

EM: Enter Monitor Mode

This message switches the device from the Normal to the Monitor mode. Query not supported.

Set format: \$PTNLSEM*hh<CR><LF>

Response to set format: \$PTNLREM, a*hh<CR><LF>

Field	Description
a	Status (A - success; V - failure)

NM: Automatic Output Interval and Mask

This message queries or sets the automatic message output.

Query format: \$PTNLQNM*hh<CR><LF>

Set or response to query format: \$PTNLaNm, hhhhhhhh, xx*hh<CR><LF>

Field	Description
a	Mode (S = set; R = response)
hhhhhhh	Message flags (32 bits maximum), one bit for each message:
	Bit 0 - GGA
	Bit 2 - VTG
	Bit 3 - GSV
	Bit 4 - GSA
	Bit 5 - ZDA
	Bit 8 - RMC
	Bit 13 - BA
	Bit 16 - TP
xx	Automatic report Interval (1 - 99)

Response to set format: \$PTNLRNM, a*hh<CR><LF>

Field	Description
a	Status (A - success; V - failure)

PT: Port Configuration

This message queries or sets the port configuration.

Query format: \$PTNLQPT*hh<CR><LF>

Set or response to query format: \$PTNLaPT,xxxxxx,a,a,a*hh<CR><LF>

Field	Description
a	Mode (S = set, R = response)
xxxxxx	Baud rate (4800, 9600, 19200, 38400, 57600, 115200)
a	Number of data bits (7 or 8)
a	Parity (N = None, O = Odd, E = Even)
a	Number of stop bits (1 or 2)
h	Input protocol(s). This is a hex bit-map. Bits can be combined to enable multiple input protocols. This field may not be 0.
	Bit 0: Reserved
	Bit 1: Reserved
	Bit 2: NMEA
	Bit 3: HIPPO
h	Output protocol(s). This is a hex bit-map. It is not recommended to enable more than one output protocol at a time because enabling multiple protocols will result in a large amount of output data which may overrun the serial port buffers and get corrupted during transmission.
	Bit 0: Reserved
	Bit 1: Reserved
	Bit 2: NMEA
	Bit 3: HIPPO

In case of Set, the Response message with new parameters is sent using the old parameters first, and then the switch to the new parameters is made. If the switch fails for whatever reason, NMEA error response is sent. If the switch succeeds, no additional response is sent.

Response to set format: \$PTNLRPT,a*hh<CR><LF>

Field	Description
a	Status (A - success; V - failure)

RT: Reset Device

This message resets the device. Query not supported.

Set format: \$PTNLSRT, a, x*hh<CR><LF>

Field	Description
a	Reset type:
	C - cold reset (clear RAM including GNSS data and user configuration)
	W - warm reset (clear ephemeris only)
	H - hot reset (RAM data not cleared)
	F - factory reset (clear RAM and NVRAM including GNSS data and user configuration)
	G - perform a graceful shutdown reset (store DR calibration data to NVRAM)
x	NVRAM (flash configuration) operation:
	0 - no operation
	2 - store user configuration to NVRAM
	5 - erase user configuration in NVRAM (set to factory defaults)
	7 - erase system configuration in NVRAM (set to factory defaults)
	8 - erase DR calibration data in NVRAM

Response to set format: \$PTNLRRT, a*hh<CR><LF>

Field	Description
a	Status (A - success; V - failure)

TP: Temperature Measurement

This message queries the temperature measurement from a specific temperature source. Set is not supported. Not all listed temperature measurement sources are supported. Refer to the product specification for details. This message is output automatically if selected in the NMEA message output mask. If selected for automatic output, the temperature sensor is used as the source of temperature measurements.

Query format: \$PTNLQTP, a*hh<CR><LF>

Field	Description
a	Source of temperature measurement:
	T - temperature sensor
	G - gyroscope sensor
	A - accelerometer sensor
	P - pressure sensor

Response to query format: \$PTNLRTP, a, x.x, x.x*hh<CR><LF>

Field	Description
a	Source of temperature measurement (same as in Query)
x.x	Temperature (°C)
x.x	Temperature accuracy (°C)

VR: Version Information

This message queries version information. Set not supported. This messages allows to query versions of various product components. Not all component versions can be queried. Refer to a particular product's specification or software design document for a list of supported components for which version information can be queried.

Query format: \$PTNLQVR, a*hh<CR><LF>

Field	Description
a	Component ID for which to query the version:
	S - system (application firmware) version
	H - hardware version
	N - GNSS / navigation software version
	D - DR library version
	C - common source code version

Response to query format for all components other than the hardware (H):

\$PTNLRVR, a, a..a, xx, xx, xx, xx, xx, xxxx*hh<CR><LF>

Field	Description
a	Component ID (same as in Query format)
a..a	Component name (variable length character string)
xx	Major version number
xx	Minor version number
xx	Build number
xx	Month (1-12)
xx	Day (1-31)
xxxx	Year

Response to query format for the hardware version (H):

\$PTNLRVR,H,xxxx,a..a,xxxxxxxx,xx,xx,xxxx,xx*hh<CR><LF>

Field	Description
xxxx	Hardware code
a..a	Hardware ID (variable length character string)
xxxxxxxx	Serial number
xx	Build month (1-12)
xx	Build day (1-13)
xxxx	Build year
xx	Build hour (0-23)




Reference Circuit

In this appendix:

- [Bison reference circuit diagram](#)
- [Circuits using externally powered antennas](#)

This appendix provides a brief overview of the Bison module reference circuit diagram.

Bison reference circuit diagram




This circuit diagram shows a reference design for embedding the Bison DR + GNSS module in your system. The diagram shows a circuit design that can be used to protect the speed signal input and FWD/REV (direction) inputs from noise and power spikes in the vehicle system. It is not recommended to connect these types of inputs in a vehicle system directly into the Bison module.

Circuits using externally powered antennas

The following circuits show how to include antenna open and short detection on the Bison module when using an externally powered antenna. In this case, the internal open and short detection will not work since the Bison will supply no power to the antenna, so the internal current measurement will not reflect the actual power in the antenna. These sample circuits allow the Bison module to detect and report on open and shorted states of the antenna, even when the antenna is powered through an external source.

Bison reference circuit for antenna Open/Short detection using an externally powered 3.5 V antenna



	VCC = 3.3	VCC = 5.0	
			1%, 125mW, resistor
R1	5.62 ohms	10 ohms	1%, 62.5mW, resistor
R2	1.0 K ohms	8.24 K ohms	1%, 125mW, resistor
R3	56.2 ohms	56.2 ohms	1%, 62.5mW, resistor
R4	10 K ohms	10 K ohms	1%, 62.5mW, resistor
R5	4.75 K ohms	5.62 K ohms	1%, 62.5mW, resistor
R6	10.0 K ohms	10.0 K ohms	1%, 62.5mW, resistor
R7	0 ohms	0 ohms	1%, 62.5mW, resistor
R8	1.0 K ohms	8.24 K ohms	1%, 62.5mW, resistor
R9	10.0 K	10.0 K ohms	1%, 62.5mW, resistor
R10	No_load	No_load	1%, 62.5mW, resistor
L1	100 nH	200 nH	Inductor, 2%, 200 mA, wirewound, SRF = 1.8 GHz
Q1	CMPT - 404A, PNP $I_c = 150\text{mA}$, $h_{fe} = 100$ min, $V_{ce} = 35$ V (Central Semiconductor)		
Q2	DMMT3904 W, Dual transistor matched pair (Diodes Inc)		
Q3	DMMT3906 W, Dual transistor matched pair (Diodes Inc)		
C1	18PF, 5%, NPO, Ceramic Capacitor, 25 volts		
C2	1UF, 10%, X7R, Ceramic Capacitor, 10 volts		